



XWEB EVO

OPERATING MANUAL (V.3.0)

TABLE OF CONTENTS

1. INTRODUCTION	6
2. THE RECIPIENTS OF THIS MANUAL	7
3. USING XWEB-EVO	7
3.1 INITIAL WIZARD PROCEDURE	7
3.2 LOCAL interface (only for models "COOLMATE")	14
3.2.1 MENU VIEW	14
3.2.2 MENU MENU	16
3.3 ACCESS TO THE SYSTEM	18
3.4 XWEB SYSTEM SETUP	19
3.4.1 INTRODUCTION.....	19
3.4.2 HOMEPAGE AND NAVIGATION BAR	19
3.4.3 SYSTEM CONFIGURATION.....	20
3.4.4 CONTROLLER CONFIGURATION	21
3.4.5 USER/BOOK CONFIGURATION	28
3.4.6 ALARM CONFIGURATION.....	31
3.4.7 STOP/START ACQUISITION	38
3.4.8 SYSTEM VERSION/UPDATE	39
3.4.9 REBOOT.....	39
3.4.10 SHUTDOWN.....	39
3.4.11 LAYOUT SETUP MODE (ONLY FOR MODELS 500D/500 AND 3000/5000).....	40
3.5 MENU TOOLS	42
3.5.1 SCHEDULER (ONLY FOR XWEB500D/500/3000/5000 MODELS).....	42
3.5.2 DEVICE LINE TEST	52
3.5.3 PERFORMANCE MANAGER (ONLY FOR 500D/500/3000/5000)	53
3.5.4 COMPRESSOR RACK OPTIMISER (C.R.O., ONLY 500/5000 MODELS).....	57
3.5.5 DEW POINT MANAGEMENT (SOLO XWEB5000).....	62
3.5.6 XWEB5000 SUPERVISOR SYSTEM (ONLY XWEB5000)	65
3.5.7 BACKUP/RESTORE.....	73
3.5.8 DAILY EXPORT	74
3.5.9 CALENDAR SETUP	76
3.5.10 DATA LOG STATUS.....	77
3.5.11 RUNTIME DATA	77
3.5.12 LANGUAGES MANAGER	78
3.6 DESKTOPS.....	79
3.6.1 DESKTOP OVERVIEW.....	80
3.6.2 DESKTOP DEVICE VIEW	84
3.6.2.1 Selection of device.....	84
3.6.2.2 Variable displaying.....	85
3.6.2.3 Modification of set-point.....	86
3.6.2.4 Start Fast Acquisition Modem (FSM).....	87
3.6.2.5 Sending commands to the device	88
3.6.2.6 Variable section for real time graph.....	88
3.6.2.7 Parameter programming.....	89
3.6.3 CHART DESKTOP	90
3.6.3.1 Graph configuration	90
3.6.3.2 Reading of graph	93
3.6.3.3 Reading the values of a particular moment.....	93
3.6.3.4 Zooming-in on area.....	94
3.6.3.5 Zooming-in on area of overview graph	94
3.6.3.6 DATA EXPORT	94
3.6.4 ALARMS DESKTOP	96
3.6.4.1 Alarm display filter	96
3.6.4.2 Alarm List Export	97
3.6.4.3 Display alarm details.....	98

3.6.4.4	Read/Write Alarm Notes	98
3.6.4.5	Check of Alarm Notifications	98
3.6.5	DESKTOP PARAMETERS	99
3.6.5.1	Parameter reading	99
3.6.5.2	Parameter writing.....	99
3.6.5.3	Parameter map saving.....	99
3.6.5.4	Parameter map loading	100
3.6.5.5	Export PARAMETERS MAP	100
3.6.6	DESKTOP SYSTEM LOGS.....	101
3.6.6.1	SYSTEM LOG EXPORT	101
3.7	SYSTEM ACCESS WITH PDA/SMARTPHONE	102
4.	TRADEMARKS	105
5.	ACCESSORIES.....	105
6.	FAQS.....	105
6.1	MAINTENANCE PROCEDURE FOR 300/500 MODELS.....	105
6.2	MAINTENANCE PROCEDURE FOR 3000/5000 MODELS.....	105
6.3	I CANNOT ACCESS THE SYSTEM WITH MY PASSWORD	105
6.4	MY BROWSER CANNOT REACH THE XWEB-EVO	106
6.5	DISPLAYING OF INCOMPLETE OR INCORRECT PAGES FROM PC.....	106
6.6	SOMEONE HAS RECEIVED A CONFLICTING MESSAGE ON THE IP ADDRESS	107
6.7	HOW MANY CONTROLLERS CAN THE XWEB-EVO MANAGE.....	107
6.8	HOW THE ALARMS ARE MANAGED	107
6.9	HOW ARE THE ALARM EMAILS RE-SENT	108
6.10	TABLET COMPATIBILITY	108
6.11	HOW TO MANAGE THE JAVA CERTIFICATES.....	109
6.12	HOW TO RUN XML READOUT	109

CAUTION: TO PREVENT FLAMES FROM DEVELOPING OR ELECTRIC SHOCK, AVOID ANY CONTACT BETWEEN THIS DEVICE AND RAIN OR WATER

	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN		CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER IT DOES NOT CONTAIN ANY PARTS THAT REQUIRE SERVICING BY THE USER ALWAYS HAVE QUALIFIED STAFF PERFORM THE PROCEDURES.
			THE SYMBOL OF THE LIGHTNING BOLT INSIDE AN EQUILATERAL TRIANGLE IS USED TO ALERT THE USER OF THE POTENTIALLY DANGEROUS NON-INSULATED ELECTRICAL VOLTAGES
			THE SYMBOL OF THE EXCLAMATION MARK INSIDE AN EQUILATERAL TRIANGLE IS USED TO WARN THE USER THAT HE/SHE MUST PAY CLOSE ATTENTION TO THE TOPIC COVERED IN THIS MANUAL

CAUTION 	This device must be installed exclusively by service staff with suitable technical training and experience, who are aware of the dangers that they are exposed to. The operations described herein are set forth exclusively for the service staff.
--	---

CAUTION 	Only use modems that are officially supported by this monitoring unit. Dixell srl cannot be held responsible for any damage caused by the use of non-supported modems.
--	--

CAUTION 	Dixell srl reserves the right to amend this manual without prior notice. The latest available version can be downloaded from the internet site.
--	---

CAUTION 	The instructions contained in this manual are standard for models "XWEB-EVO 300D" / "XWEB-EVO 500D" / "XWEB-EVO 500" / "XWEB-EVO 3000" / "XWEB-EVO 5000". Any particular features are specified expressly.
--	--

CAUTION 	This control and monitoring unit fulfils EN 12830 for use with probes to detect measurements referred to in 13485
--	---

CAUTION 	This is a class A product. It can cause radio-interference in residential environments. Should this occur, the user should take suitable counter-measures
--	---

CAUTION 	Dixell srl reserves the right to vary the composition of its products without prior notice to the customer, ensuring the identical and unchanged features of the same
--	---

1. INTRODUCTION

Congratulations for having purchased this product.

XWEB-EVO represents one of the most advanced monitoring, control and supervision systems available on the market today. The user will benefit from a power tool, which is easy to use and highly customisable for all requirements. It uses the most advanced technology for displaying the web pages and is based on the Linux™ operating system which guarantees its efficiency and reliability. The hardware is based on highly reliable industrial boards that require practically no maintenance whatsoever.

The web interface is made available locally on models XWEB3000 / 5000 EVO WITH a monitor, mouse and keyboard directly connected to it. A local interface on the display and keyboard, is also available on the model XWEB500D.

Remotely and for all models you can use the web interface by logging on with a regular computer with internet browser, such as Internet Explorer®, or Mozilla Firefox®.

XWEB-EVO, for models 300D / 500D can easily be DIN rail. The model 500 wall. Models 3000/5000 to desk or 19 "rack.



XWEB-EVO is designed and bases its operation not only on the Dixell network of controllers. Its main applications are supermarkets of any size, industrial refrigeration and air conditioning.

In addition to the normal monitoring systems, XWEB-EVO provides (for all models):

- the recording of temperatures in compliance with food hygiene standards UNI EN 12830, HACCP
- the tracking and management of system and control alarms (and centralised management for the XCenter product)
- the management of controllers with planned operations (only for 500D/500/3000/5000 models)
- the programming of controller parameters
- Compressor Plant Management (Compressor Rack Optimiser, CRO). To better manage the availability of cooling power;
- and much more


The following tools are added to the XWEB-EVO 5000 models:

- Supervision (SPV). For load control, light control, etc.;
- Anti-Sweat Heater Control (DEWP). Useful for the management of the anti-sweat heaters

These tools are particularly useful for Energy Saving optimisation.

DIXELL SOLUTIONS

- SUPERVISING
- CRO (Compressor Rack Optimization)
- COMPRESSOR RACKS MANAGEMENT
- ANTI-SWEAT HEATER CONTROL



2. THE RECIPIENTS OF THIS MANUAL

The contents of this manual are intended for professional users, such as the XWEB-EVO installer and/or its end user. The configuration and usage procedures of the XWEB-EVO are an integral part of this manual. Users may be professionals such as energy-managers or supermarket directors.


In addition to this manual, we also recommend reading the installation manual provided in paper form, inside the product package, and in electronic form on the Dixell site, under the "manual" section.

3. USING XWEB-EVO

3.1 INITIAL WIZARD PROCEDURE


The first time the machine is switched on, the XWEBEVO will ask the user carrying out the installation to specify some essential parameters for the operating of the machine. The screens listed below make up the "initial wizard" procedure through the webserver, if you directly connect to xweb using the default address <http://192.168.0.150> (for 300D/500D/500 models) or <http://192.168.0.200> (for 3000/5000 models). For XWEB3000/5000 models the same pages are available from the local interface.

- a) Initial wizard language.



To specify your preference, click on the flag. The Initial configuration wizard will continue in the chosen language.


- b) System language / Local keyboard (for XWEB3000/5000 models only)



System language. It represents the language that the system uses for the parts that do not refer to a user, thus to its language. For example, for alarm or system notifications. To specify your preference, select the language from the list and press "Next". This language is also used for the Admin user.


Local keyboard. Indicate the configuration of the keyboard physically connected to the XWEB. Once you have selected your preferred parameters, press "Next" to continue with the procedure.

c) System Identification.

The screenshot shows a 'System Configuration' window with a progress bar at the top. The current step is 'System Identification'. It contains four input fields: 'System Name' with the value 'XWEB EVO', 'System Description' with 'XWEB EVO', 'System Email Address' with 'example@domain.com', and 'System Telephone Number' with '1234'. At the bottom right, there are 'Previous' and 'Next' navigation buttons.

These boxes describe the system, displaying both the name and several parameters that can be used to indicate to the user the references of those in charge of maintenance or servicing of the machine. Once you have selected your preferred parameters, press "Next" to continue with the procedure.

d) Date/time time-zone setup

The screenshot shows a 'System Configuration' window with a progress bar. The current step is 'Date/Time Timezone Setup'. It includes several settings: 'Time Zone' set to 'Europe' with a sub-selector for 'Rome (+1)'; 'Date Format' set to 'DD/MM/YYYY'; 'Time' set to '12:02'; 'Date' set to '10/03/2015'; 'Date/Time Synchronization' with radio buttons for 'Manual', 'Daily' (selected), 'Weekly', and 'Monthly'; and 'NTP Server Address' set to 'pool.ntp.org'. 'Previous' and 'Next' navigation buttons are at the bottom right.

Configuration parameters of the XWEBEVO time. The time can always be changed by hand; or automatically synchronised with an NTP time-server with a daily/weekly/monthly interval. We recommend using an NTP server that is geographically in your vicinity, for example, in your own country. We recommend asking your network administrator for the name of the NTP server that will be used.

e) Network setup.

The screenshot shows a 'System Configuration' window with a 'Network Setup' tab. The window has a dark theme. The configuration fields are as follows:

Field	Value
XWEB LAN IP Address	192.168.0.200
IP Mask	255.255.255.0
Gateway IP Address	192.168.0.1
DNS1 IP Address	
DNS2 IP Address	
Hostname	Xweb010
Domain Search Name/IP	

Below the fields, there are two checkboxes:

- ☒ Automatic Configuration from DHCP Server
- ☐ Use XWEB as DHCP Server


At the bottom, there are two buttons: '< Previous' and 'Next >'.

For the XWEB network interface configuration. Normally, these parameters are to be agreed with the network administrator, so it is advisable to contact him/her for guidance and support.

- '*Lan enable*': disable the check to use the XWEB with local interface only (monitor and keyboard). In this way, it will not be possible to access the server by means of the local network or internet. Disabling is not a common procedure: if in doubt, keep this box enabled.
- '*Automatic DHCP*': enable this box if your network provides a DHCP server and if you want it to inform the XWEBEVO regarding which IP to use. Disabling implies that the user configuring the XWEBEVO must explicitly indicate the following parameters:
 - Hostname
 - IP Address
 - IP Mask
 - Gateway IP Address
 - DNS1 IP Address
 - DNS2 IP Address
 - Domain search name/ip address
- '*Host name*'. Name identifying the machine within the network. Example XWEB0001
- '*IP Address*': is the unambiguous address used to access XWEB. There are two types of IP addresses: private and public. The first are used when the clients connected to the network must not be externally reachable; a closed environment is created where communication is only enabled between the network PCs. 192.168.x.y is an example of a private address. The public IPs are used when there is need for visibility on the Internet.
- '*IP Mask*': is a filter that allows for the routing of the packs directly to clients belonging to the subnet mask. For example, a subnet mask 255.255.255.0 enables XWEB to directly reach only the PCs with IP addresses compatible with the mask, with the exception of the last octet. All other requests are routed to the gateway (if present).
- '*Gateway IP*': The Gateways are devices that handle the routing of the network traffic that is unable to directly reach the destination IP. Example 192.168.0.1
- '*DNS1/DNS2 IP Address*': In order to reach a web server on the internet, you must enter the name, e.g. www.dixell.com, in the Browser address bar. In fact, following the use of specific communication protocols required to guarantee the efficiency and the safety of the network, the name is converted into a number (the IP address). This operation is performed by a DNS server. The ISP or network administrator can normally provide a DNS server. Example 10.100.1.20
- '*Domain search name/ip address*'. Example MYCOMPANY.COM
- '*2nd web-server port*': is the network port on which the web server is listening. The default port is number 80. However, for some network needs, it may be necessary to change the default port value (port 81 and 8080 may be the values normally used).

- 'Enable local DHCP Server': it makes sense to enable this function only if you do not wish to connect the XWEB to a network but only to a PC, where the network interface does not specify an IP. If in doubt, keep this box disabled to avoid network conflicts.
- 'Enable net speed negotiation': enables the automatic speed adjustment of the board with the network, after a link-down event.

f) Modem setup



XWEB requires a modem to send faxes and, in some cases, to send emails. In the first case, the system works independently, whilst in the second, it is necessary to configure the dial-up connection (see next point). Attention: only Dixell-approved modems can be used.

Possible options:

1. Disabled
2. Dixell internal modem. It is internal analogic modem
3. Dixell external modem. Its is XWEBMODEM external modem
4. External GPRS modem. It is TC35-KIT external modem
5. Internal GPRS modem. It is al modem interno GPRS (not supported)
6. External generic modem.

g) Dial-up setup.



The configuration of the dial-up parameters is necessary to establish a connection with the internet provider via the modem; for sending emails. This is also useful in cases where the XWEBEVO is connected to the local network via an Ethernet cable yet there is no access to the mail sending server. The configuration parameters are always supplied by the provider; refer to this documentation.

h) Email setup.

The screenshot shows the 'Email Setup' configuration screen within the 'System Configuration' application. The interface is dark-themed with a sidebar on the left containing navigation tabs numbered 1 through 10. The main area is titled 'Email Setup' and contains the following fields and controls:

- Enable Email Forwarding:** A toggle switch currently set to 'Off'.
- Default Email Server (Name/IP):** A text input field.
- Authentication Type:** A dropdown menu currently showing 'No authentication'.
- Authentication Username:** A text input field.
- Authentication Password:** A text input field.
- Default Forward Service:** A dropdown menu currently showing 'Forward through LAN'.
- Maximum Retry Number:** A text input field with the value '0'.
- Retry Delay (minutes):** A text input field with the value '0'.
- On Error Forward Service:** A dropdown menu currently showing 'Select forward service'.
- Maximum Retry Number:** A text input field with the value '0'.
- Retry Delay (minutes):** A text input field with the value '0'.

At the bottom of the screen, there are two buttons: 'Previous' (with a left arrow) and 'Next' (with a right arrow).

The XWEBEVO is able to send emails, generally to notify updates on the status of alarms. To enable this function, it is necessary to enable the service by completing the configuration. The configuration parameters can be supplied by your internet provider or by your network administrator.

The XWEBEVO supports different types of authentication protocols:

- No authentication
- User/Name normal
- User/Name TLS (without STARTTLS)
- User/Name TLS
- User/Name SSL

The TLS protocol is associated with ports 25 and 587; the SSL protocol is normally associated with port 465.

i) SMS setup.

The screenshot shows the 'SMS forward' configuration screen within the 'System Configuration' application. The interface is dark-themed with a sidebar on the left containing navigation tabs numbered 1 through 10. The main area is titled 'SMS forward' and contains the following fields and controls:

- Sms forward enabled:** A toggle switch currently set to 'Off'.
- Send sms trough service:** A dropdown menu currently showing 'Select forward service..'.
- Sms machine name:** A text input field.
- Sms forward activation code:** A text input field.

At the bottom of the screen, there are three buttons: 'Previous' (with a left arrow), 'Next' (with a right arrow), and 'Power off' (with a power icon).

The XWEB is able to send short text messages via SMS. Some types of services can be used:

- via Netech Gateway on LAN. Visit the following link: http://www.netech.it/ir_smsalert to configure the SMS. After having completed the online registration form, you will receive an email with an activation code that you must include in the XWEB configuration.
- Via sopen KOREA Gateway. If your XWEB is connected to the Internet and want to send SMS in Korea using the service sopen (available only in Korea)

- Via RAVEN XE gateway. If you have connected to the modem XWEB raven XE, you can use it to send messages using your phone bills.

j) Printer setup (only for XWEB3000/5000)

The printer can be connected locally or use a network printer. To obtain a list of tested printers, go to www.dixell.com and visit the XWEB support section or click on the following link: <http://www.emersonclimate.com/europe/ProductDocuments/DixellLiterature/PrintersXWEB.pdf>

Local printer

Once you have selected the local printer, select the port that the printer is connected to through means of the Local printer list box and then select the correct print driver. If your printer model is not listed, select the model that is most similar in terms of name and presence from the list.

Windows network printer

Once you have selected Windows Network Printer, the system automatically searches for the available network printers. After a few minutes (based on the size/complexity of the network), the full list of printers will appear. If your printer does not appear in the list, it cannot be used; try to repeat the search procedure. After having selected the printer, select the appropriate print driver. If your printer model is not listed, select the model that is most similar in terms of name and presence from the list.

k) XCenter Notification Setup (not available in the initial Wizard but only by going to the System Setup)

You can configure your XWEB to communicate with the system XCenter centralized management for Call Centers.

l) Auxiliary output setup (only for 500, 3000/5000)

- Auxiliary Output Setup

The boxes set the normal logic for relays AUX XWEB. Disabling the box 'follow alarm delay' makes energize relay in sync with the reading of the state of alarm.


- Outputs Remote Device Setup (not available during the initial wizard)

This section is used to configure any XJR40D to use it as an extension of the alarm relay of XWEB.

- Digital Inputs (not available during the initial wizard, only to xweb500evo)


This section is used to configure commands to be sent to the tools configured on the network Modbus / 485 during state changes of the digital input.

m) Wizard conclusion



The first configuration procedure is now complete: press "apply" to apply the configuration and reboot the system.

The following screen may appear while the system is rebooting.



Wait a few minutes after rebooting to be able to access the login page.

3.2 LOCAL INTERFACE (ONLY FOR MODELS "COOLMATE")

The local interface consists of 8 keys:

TASTO	FUNZIONE
VIEW	Direct access to the archive and live data
MENU	Access to the configuration menu
CLEAR	Exit the current menu; delete character
ENTER	Entry into menu; Open list current alarms
←	Left shift
▲	Move up
▼	Move down
→	Right shift

And generally the interface presents to the voices in the symbol →

To access some screens, you must enter a valid username and password of a user registered in the system. The credentials entered remain valid for 5 minutes.

The main screen, when the system does not detect any alarm, the LCD shows:

```

X W E B 5 0 0   E V O
X W E B   E V O 1 2 3 4
A c q u i s i t i o n
0 9 : 1 8   1 8 / 0 9 / 2 0 1 5

```

When the system detects alarms, the LCD shows:

```

X W E B 5 0 0   E V O
X W E B   E V O 1 2 3 4
A c q u i s i t i o n
A c t i v e   A l a r m s :   8

```

3.2.1 MENU VIEW

From the main screen, pressing the VIEW you access the menu

```

      V i e w
→ D a t a
  A l a r m
  T o o l s

```

The complete menu is composed of the

```

View_
|___ Data
|   |___ Actual
|   |___ From Archive
|       |___ Main Data
|       |___ Circular Data
|___ Alarm
|       Access denied insert username and password
|       Exit Save Caps abcd...z
|           |___ Actual
|           |___ From Archive
|               |___ Last 3 days
|               |___ Last 3 days by device
|___ Tools
|   |___ Line test
|___ Mute buzzer

```

- The menu data allows you to view current data or archive
- The menu alarm can display current data or archive
- The menu utility provides access to test the RS485
- The menu mute buzzer allows you to stop the sound of the buzzer, potentially active on alarm

CURRENT DISPLAY AND CHANGE OF CONTROL POINT AND ENTER

Current data from the menu you can select a tool and change the setpoint. The current view is the following:

```

R S 1 - 0 0 2   N e w _ X R 1 7 0 C
. > - - - - - A N A L O G - - - - - <
E v a p o r a t o r   ( P b 2   - 7 .
R o o m   ( P b 1 )   - 1 0 . 8   ° C
> - - - - - S T A T U S - - - - - <
O n :   O N
> - - - - - S E T P O I N T - - - - - <
S e t   P o i n t   1 . 3 ° C
> - - - - - A L A R M - - - - - <
E E P R O M   F a i l u r e :   O f f
E r r o r   P b 3 :   O f f
E r r o r   P b 1 :   O f f
O p e n   D o o r :   O n
> - - - - - I N P U T - - - - - <
G e n e r i c   A l a r m :   O f f
> - - - - - O U T P U T - - - - - <
C o o l i n g :   O f f
A l a r m :   O f f
D e f r o s t :   O f f

```

To change the current setpoint, the setpoint position and press ENTER, change the set using the "up arrow", "down arrow" and press ENTER.

DATA FROM ARCHIVE

Menu data archive you can select a tool and the variable of interest (for example probe "Room (Pb1)") and scroll through the value on the selected time intervals.

Please select 'information circular' to retrieve samples

```

                R o o m   ( P b 1 )
1 8 / 0 9 / 2 0 1 5   1 1 : 5 1 : 2 3   - 1 0 . 8 ° C
1 8 / 0 9 / 2 0 1 5   1 1 : 4 6 : 2 3   - 1 0 . 8 ° C
1 8 / 0 9 / 2 0 1 5   1 2 : 0 1 : 2 3   - 1 0 . 8 ° ↓

```

ALARMS VISUALIZATION

The alarm menu, enter your username and password valid for the display of the same, you can see alerts

1. Actual and active

```

                A c t i v e   A l a r m s
➔ 5 9   ( R S 1 - 0 0 2 )   N e w _ X R 1 7 0 C
    5 8   ( R S 1 - 0 0 2 )   N e w _ X R 5 7 0 C
    5 7   ( R S 1 - 0 0 2 )   N e w _ X R 1 7 0 ↓

```

Selecting the alarm hano details alarm. The information is as those of example:

```

      A c t i v e   A l a r m s
. C o d e :    5 9
A d d r e s s :   R S 1 - 0 0 2
D e v i c e :   N e w _ X R 1 7 0 C
C a t e g o r y   D e f a u l t
N a m e :    O p e n   D o o r
S t a r t :    2 0 1 5 / 9 / 1 8    1 0 : 1 1 : 2 8
E n d :    A c t i v e
D u r a t i o n :   A c t i v e

```

2. From archive

```

      A l a r m   A r c h i v e
. C o d e :    6 9
A d d r e s s :   R S 1 - 0 0 2
D e v i c e :   N e w _ X R 1 7 0 C
C a t e g o r y   D e f a u l t
N a m e :    O p e n   D o o r
S t a r t :    2 0 1 5 / 0 9 / 1 8    1 4 : 4 5 : 1 3
E n d :    2 0 1 5 / 0 9 / 1 8    2 1 : 4 3 : 1 4
D u r a t i o n :   0 6 h   5 8 m
T e r m i n a t e d   B y   S E L F
N o t e s   P r e s e n t
N o t i f y   N o t   P r e s e n t

```

3.2.2 MENU MENU

From the main screen, pressing the MENU key the user accesses the menu

```

      M e n U
→ S e t u p
   V i e w
   D e v i c e   C o m m a n d   ↓

```

The complete menu is composed of the

```

Menu__
|__ Setup
|   |__ Access denied insert username and password
|       Exit Save Caps abcd...z
|           |__ XWEB500 EVO - Device
|               |__ Language
|               |__ Identification
|               |__ Delete archive
|               |__ Network
|               |__ e-mail
|           |__ Start-Stop Acquisitions
|               |__ Start Acquisitions
|               |__ Stop Acquisitions
|           |__ Date / Time
|               |__ date
|               |__ hour
|               |__ Format
|               |__ NTP server

```

```

|          |__ Sync mode
|          |__ Devices
|              |__ Add
|              |__ Delete Single Device
|              |__ Delete multiple devices
|
|__ View
|    |__ ( come menu VIEW, vedi sopra )
|
|__ Device Command
|    |__ Access denied insert username and password
|        Exit Save Caps abcd...z
|
|__ Global command
|    |__ Access denied insert username and password
|        Exit Save Caps abcd...z
|        |__ command 1
|        |__ command 2
|
|__ Logout
|
|__ About

```

- The account setup allows the configuration of the machine parameters XWEB
- The menu view allows you to view current data or archive
- The menu command device allows sending commands to instruments

```

      D e v i c e   C o m m a n d
→ R S 1 - 0 0 1   N e w _ X R 5 7 0 C
  R S 1 - 0 0 2   N e w _ X R 1 7 0 C
  R S 1 - 0 0 3   N e w _ X R 5 7 0 C ↓

```

```

  R S 1 - 0 0 1   N e w _ X R 5 7 0 C
→ D e v i c e   O F F
  A l a r m   M u t e
  K e y b o a r d   U N - L O C K
  D e v i c e   O N
  A c t i v e   D e f r o s t
  K e y b o a r d   L O C K
  E n e r g y   s a v i n g   A c t i v e
  E n e r g y   s a v i n g   N O T   A c t i v e

```

- The global voice-command is used to send commands to groups of instruments, as well as configured on the desktop 'overview'
- The menu logout force entry of the user name and password for future operations that require it
- The menu About allows the display of information related to the model


```

      A b o u t
. S o f t w a r e :   3 . 0 . 0 - A 7 - - 4 a 5 d
M a x   D e v i c e s :   5 0
C o d e :   J N P P B Z Z 5 0 0
M A C :   0 0 0 A F 1 2 3 4 5 6 7

```

3.3 ACCESS TO THE SYSTEM

Access the system from your PC by entering the XWEBEVO IP in the browser address bar. With a direct local connection [screen, mouse and keyboard], this operation is not required, simply switch on the screen.

The image shows a login screen for the XWEB EVO system. At the top left is the 'Dixell' logo, and at the top right is the 'EMERSON Climate Technologies' logo. The main heading is 'Welcome to XWEB EVO', followed by the instruction 'Insert your username and password to login'. Below this are two input fields: 'Username' with a red border and a cursor, and 'Password' with a red border. A 'Login' button is positioned below the password field. At the bottom, it says 'XWEB500D EVO - Xweb EVO - 12/03/2015'.

The user will be directed to the "login" page. From which all users will consistently have access to the system's user interface.

Enter Username and Password to access the system. If the entered details are correct the homepage is loaded, otherwise repeat the operation. Pay attention to the presence of alphanumeric characters or capital letters in the password.

You can only connect to a system being accessed for the first time, which has just completed the "initial wizard" procedure, with:

Username: Admin

Password Admin

Attention: change this password as soon as possible; anyone can read this manual and come into

possession of the access details. Icon  may appear bottom-right. It represents the case in which the XWEBEVO is already operational and an alarm has been detected (e.g. high temperature). It will be necessary to login with a valid username and password to be able to recognise the type of alarm and to analyse the system situation. The alarm icon does not automatically assume that the XWEBEVO has activated the relay outputs (e.g. to pilot an alarm siren) nor that someone has been notified of the alarm. This depends on how the administrator has decided to configure the XWEBEVO.

Icon  may appear bottom-left. It represents cases in which access to the user interface by non-administrator users has been blocked. This block is normally executed to indicate a system maintenance operation by a specialised operator.

3.4 XWEB SYSTEM SETUP

3.4.1 INTRODUCTION

In its configuration, the XWEB-EVO system requires connection to its interface of Modbus devices. Make sure that:

7. the controller network is suitably connected paying particular attention to the configuration of the device addresses, to avoid non-admitted duplications.
8. all instruments are properly powered. Create the list of all connected instruments. Then compare this list with the number of instruments effectively detected by means of the automatic procedure

The XWEBEVO allows for the management of different device lines (also called "nodes"), which can use different types of physical connections and configurations for communication. Obtain the network documentation.

3.4.2 HOMEPAGE AND NAVIGATION BAR

The page that the XWEB-EVO displays on login is the "Desktop Overview". This is further detailed later in the manual, in the section relating to Desktops.

The user can also browse the other main pages that are grouped in the DESKTOPS menu of the navigation bar. Or in other pages, typically for configuration, present in the MENU section.


The navigation bar is always visible on all pages and it enables the user to run the LOGOUT, in other words, to display the interface on the page requesting the username and password.



The user is provided with additional information in the navigation bar, such as:

- Date and time of system

- Information on connected user



- State of access block to "non-admin" users.  block active;  block not active.

Click on the padlock icon to activate and deactivate the block: a dialog will appear to confirm the operation. When the system is blocked an indication appears on the login page.

- State of the acquisitions.  active;  not active

- State of the alarms. At least one active with icon present 

The other pages can be accessed from the navigation bar by clicking on the icons

-  Desktop Overview
-  Desktop DeviceView
-  Desktop Chart
-  Desktop Parameters
-  Desktop Alarms

The DESKTOPS and MENU menus can be accessed by clicking on the buttons on the right-hand side of the same page.


For the DESKTOPS pages, navigation is carried out via the carousel from which the user can choose the desired page.



Alternatively, it is possible to scroll down the pages using keyboard short-cuts:

ALT-H (Desktop Overview)
ALT-W (Desktop DeviceView)
ALT-G (Desktop Chart)
ALT-P (Desktop Parameters)
ALT-A (Desktop Alarms)
ALT-L (Desktop System logs)

For the MENU pages, navigation is executed through means of the connections in the "XWEB SYSTEM SETUP" and "TOOLS" sections.



The user can access the desired section by clicking on the name.

3.4.3 SYSTEM CONFIGURATION




The XWEB system is configured upon machine commissioning, via the "initial wizard" procedure described in the chapter.

Subsequently, the system configuration can be modified by accessing the MENU→XWEB SYSTEM SETUP→System Setup. See chapter 3.1 - INITIAL WIZARD PROCEDURE.

3.4.4 CONTROLLER CONFIGURATION





The controller-device configuration phase allows for the association of each connected device with the system. For each device, the system will be able to represent and configure its attributes and functions. The system will, in relation to the selected device, only show the attributes (categories, alarms, inputs, etc..) typical of the device itself. To be able to modify the faulty configuration parameters, the acquisitions must be switched off. Should they remain switched on; an error message will appear upon accessing the page:



When entering configuration mode, from this page it will be possible to launch the following operations:

A. DEVICE FIND

Performs a search of the controller network for the Dixell devices. This procedure is automatically launched when no device has been configured. This procedure can also be manually run in the next phase when the tools are already configured, by accessing the tab "Find".



To perform the search for the controller devices (also called "nodes")

1. Specify a protocol.

- **dixell485**: controller search, optimised for wired networks (no wireless)
- **dixell485xev**: controller search, optimised for wired XEV modules (no wireless)
- **dixell485-icool**: controller search, optimised for wireless networks (using the iCOOLL modules)
- **mb485tcpip**: controller search, Modubus-485 connected on tcp/ip gateway
- **mbtcpip**: Modbus search on tcpip

2. Specify the 485 serial line

The XWEB300/500EVO models can manage 1 serial line. The XWEB3000/5000EVO simultaneously allows for the management of 2 serial lines. Each line can address a maximum of 247 devices.

3. Specify whether or not the system must run the search by controlling the silence time. The enabling of this parameter allows for the stopping of the search procedure should noise be detected on the line.
If in doubt as to whether or not to enable this function, disable it.
4. Specify the Modbus range of addresses to be detected
5. Press "Start search" to run the operation.

The search results may display the list of detected devices that can be added to the network configuration. The presence of the system device library is indicated in the "Library" column with the symbol ✓. The missing library must be installed should another symbol be displayed. The name of the device and the group of pertinence can be configured when the row is selected (as shown below).

Devices found							
☐	Library	Address	Network	Name	Group	Rel.	Map
☒	✓	2	Line 1 485	New_XR570C	Default	2.0	4
☐	✓	3	Line 1 485	New_XR70CX	Default	1.0	1
☐	✓	5	Line 1 485	New_XR170C	Default	2.0	4
☐	✓	7	Line 1 485	New_XR170C	Default	2.0	4

To confirm the configuration of the devices, select them and press "Apply".


Attention: from this window it is not possible to replace the set-up of controllers already present in the configuration. If at least one of the selected addresses is already present in the "Device List", you will receive an error message:

The screenshot shows the 'Device List' on the left with one entry: '2 --- New_XR570C'. The main window has tabs for 'Device Resources', 'Group Manager', 'Template Manager', 'Find', and 'Add/Remove Device(s)'. The 'Find' tab is active, showing the 'Devices found' table. The 'Apply' button is highlighted with a red box and the word 'click' next to it. An 'Alert' dialog box is displayed in the foreground with a warning icon and the text: 'Some addresses are already present on the system, please modify your parameters and retry!' with an 'OK' button.

If you have changed a physical device and need to replace it in the system configuration, you must first remove it from the device configuration.


B. ADD/REMOVE DEVICES, MANUAL SETTING

The association with the instrument network configuration can be manually added or removed to/from the controller devices by the user. You must access the "Add/Remove Device(s)" tab.



The list of all the libraries in the system is displayed in this window.

- Add a device
 1. Select the library to be used from the list:



2. Run the Drag'n'Drop on the "Add Device(s)" area:



3. Specify the configuration parameters of the devices on the network.

Add device(s)

Protocol selection

dixell485

Peripheral

Line 1 485

How many devices?

1


From Address

Cancel

Add

The correct execution of the procedure will update the left-hand side of the screen with the list of configured controllers.

- To remove a device
1. Select the device you wish to remove from the network configuration




2. Run a drag'n'drop on the "Remove Device(s)" area. Attention: to correctly execute the drag, click on the dotted area
3. Confirm the removal

C. CONFIGURATION OF THE DEVICES-GROUPS


The user can assign controller devices to groups so as to order the configuration according to a functional diagram or physical positioning within the supermarket.

The separate representation of the groups can be seen in the main "Overview" page.

Access the "Group Manager" tab to configure the groups.



- To add a group
1. Press the "Add group" (+) key




2. enter the name of the group. E.g. "BT"
3. Select the devices to be added to the group. Keys SHIFT and CTRL can be used for multiple selection.
4. Run the drag'n'drop of the devices on the group box. Attention: to correctly execute the drag, click on the dotted area

It is also possible to assign the devices to the groups directly using the "Device Find" procedure.

D. RESOURCE CONFIGURATION OF DEVICES

It is possible, for the devices already added to the controller network configuration, to customise their resources. For example, the variable name as well as other features. Select the "Device Resources" tab to access this feature.



- Customisation of device name.
- Enable Device

No: by enabling this option, XWEB not query the device and therefore no value from the device is displayed. This option is useful when you want to create pre-device configurations but will not fit them to keep them in a real network context.

Yes, not logging in OFF mode: by enabling this option, XWEB interrogates the device. In the event that the device is in ON displays the data in real time keeping them stored in the historical archives. In periods when the device is OFF, the device data are not available.

Yes, not logging in OFF mode: by enabling this option, XWEB interrogates the device. Both in the case that the device is in the ON or OFF displays the data in real time keeping them stored in the historical archives. This option is useful in case the tool should be used as a 'probe'; the data read from the instruments in OFF are not always valid and should be checked with Dixell on what tools to use this function.

- Main Sampling (mm:ss)

Registration time of main history data. This time represents the maximum resolution of each sample, after the two days of sampling.


- No-Link timeout

Time after which the system detects the condition of the disconnected device.

- XWEB Clock-Sync

Enable the XWEB in order to synchronise the instrument clock. This option is only available for devices with RTC. The update operation is automatically run by the system on a regular basis.

- Customisation description of variables and of the unit of measure
1. Select the variable of which you wish to change the description. The string can be edited by typing in the "Custom name" or "Unit" column.



☐	Original Source	Custom Name	Unit	Sdsc
Analog (3)				
☐	Evaporator (Pb2)	Evaporator (Pb2)	°C	
☒	Room (Pb1)	Sonda temperatura stanza	°C	

- Registration in threshold main data (Red.Edge) and not sampling (only for digital type variables).

This function allows you to keep the thresholds unaltered, even below the sampling times for the main data for the variables selected, in order to allow for the detailed graphical representation of the same variables, even after two days. To enable the function, tick the box relating to the variable in the "Sodsc" column. Attention: the enabling of this function can also drastically reduce the overall memory of the XWEB history. Only enable this function for short periods of a few days.

- Enabling of the variable for "DeviceView" page.


The variable is inserted in the DeviceView page if the box corresponding to the same variable is enabled. By default, each variable is enabled in this context.

- Enabling of the Notify variable

The variable is inserted in the snapshot table, in the instrument notifications. For example, as seen in the image below, the variable is inserted in "Row 3" of the table. All values in this table are relative to those displayed when the notification is sent.


- Enabling of the Graph variable

The variable is inserted in the snapshot graph, in the instrument notifications. For example, as seen in the image below, the variable is inserted in "Row 4" of the graph.



- Clone configuration of an instrument

The XWEB-EVO allows for the cloning of the configuration of a device to reduce the number of configuration operations on the network instruments. To do this, select the source control and click on "Clone Settings".



From the drop-down menu select:

- "Everything": applicable only to compatible instruments. For a copy of all device parameters.

- “Common Settings”: applicable to all instruments. For a copy of only the compatible parameters that can be detected on the destination device.

Select the devices to which you wish to apply the copy of configuration parameters on the network and click OK. The ‘name’, ‘sampling’, ‘no-link time out’ and ‘clock syncro’ parameters, at this point, are all duplicated alongside all descriptions of the variables and their display parameters.

Advanced configuration of the device


Press “Switch Mode” at the top-right to access the advanced configuration parameters



The user can configure the variable description (resources) of the device and for each of these, configure:

- Sampling: specific acquisition time of the resource. If set at 00:00, the acquisition time will that which is global for the device ("Main Sampling"). By default this parameter is set at “00:00”. This parameter is relative to all resources available being read by the device and not for the controls.
- Save: data-logging enabling for the variable. If this checkbox is disabled, the variable is displayed in real time on the runtime/device-view page but the history of its trend will not be maintained. This parameter is enabled by default. This parameter is relative to all resources available being read by the device and not to the controls.
- Reading Frequency: this parameter sets the activities on the polling cycle for the resource. Disabled debilitates all resource reading and writing operations; each X to enable them where X is the delay in the polling rounds. By default this parameter is set to Disabled or Each 1 (variable management for each polling round, for analogue and digital resources) or Enabled for control resources.

Export template




Apply configuration




The Apply key is used to apply any changes to the configuration made on the Web-Browser to the XWEB-EVO system. We recommend applying the configuration to even the smallest of modifications.

E. DEVICE TEMPLATE CONFIGURATION



The configuration of a device can be imported into the Template gallery. These devices can then be setup using the "Add/Remove Devices" section as demonstrated in the image below




3.4.5 USER/BOOK CONFIGURATION




The user configuration page allows for the configuring of the XWEB-EVO book. This book is unified in the system for all operations involving external users. Users are intended, for example, as those who have access to the web interface; users can also be those receiving alarm notifications. Upon the system commissioning, there will be a single user configured and enabled: Admin. For which full access to the Web interface in English is guaranteed. The user belongs to the "superadmin" profile. The user with right to access this page can:

- Display/modify the access rights of users



Clicking on the user list updates the section on the right-hand side of the screen with the "User Details" and "User Permissions". To apply the changes to these system sections, press "Save" on the "Users" section. To delete users, select the desired user and press "Delete". Attention: it is not possible to delete the 'superadmin' profile user; Attention; the user permissions may differ from those set on the profile indicated for the same user: the profile name is that of default which was used to create the user.


- Display/modify the profile rights



Clicking on the profile list updates the section on the right-hand side of the screen. By accessing the "Profile Permissions" section, it is possible to browse and/or modify the profile attributes. For any modifications to be applied to the system, they must be confirmed by pressing "Save" in the profile list.

- Create/Delete profiles

Click on "New" in the profile section to add a profile.




Name the profile and select the starting profile: the new profile will have the same access rights as those of the starting profile.

To delete a profile from the system, select it and press "Delete" in the profile area. Attention: the superadmin/admin/user profiles cannot be deleted.

- Create/Delete users

Click on "New" in the user section to add a new user.



Complete the compulsory data and press "Confirm". Each user is created with the selected profile permissions. The username/password parameters are for web access. Name and Last name are the terms with which the user will be indicated in the book.

- Desktop and user/profile permission parameters



The user permissions enable him/her to perform a number of operations.

Access to the desktops is configured in the Desktop section and the main desktop that is accessed immediately after login is set.

3.4.6 ALARM CONFIGURATION



The alarm configuration is accessed from the MENU→XWEB SYSTEM SETUP→Alarms Management. Access to the page allows for the customisation of the alarm categories and notification parameters: The XWEB-EVO uses this information to detect the alarms from the controllers and notify their status to the users in the book.

- Principles of operation

The XWEB-EVO detects the present controller alarms in an alarm-category. Once the device alarm has been detected, the system confirms this after a certain period of time (see Delay parameter, "alarm category parameters"). Upon alarm confirmation, the first level users are also notified. If the alarm persists, other notifications may be sent to the same recipients (see re-send time, "alarm level parameters"). If the alarm persists beyond the maximum time permitted to the level (see re-send life time, level parameters), the level shifts, sending the subsequent notifications to the recipients of the subsequent level. The alarm recovery is also normally notified: there are many parameters that can be used to customise notifications according to your requirements; these will be individually described in the following pages.

System Name: XWEB5000 EVO	
Date/time:	Wed May 30 09:50:24 2012
Nome categoria allarme:	Default
Level name:	Test Level 1
From:	xweb5k-evo@email.com
To:	Luca.lucicello@emerson.com


21 NEW ALARM(S)

						Row
Device	XM679K New_XM679K			A/14		1
Alarm name	Started	Ended	Duration	Term.	Alarm Code	
High SuperHeating	30/05/2012 09:49:49				0000000403	2
MOP	30/05/2012 09:49:49				0000000407	3
LOP	30/05/2012 09:49:49				0000000411	4
EEPROM Failure	30/05/2012 09:49:50				0000000415	5
Pressure Probe Alarm	30/05/2012 09:49:50				0000000419	6
Error Pb4	30/05/2012 09:49:50				0000000423	7
Set Point:	Regul. SSH: 0.00 °C	Set Dew Point: 0.00 °C				8
Probes:	Probe 1: 0.00 °C	Probe 5 temp: 0.00 °C	Regul. Probe: 0.00 °C			
	Superheating: 0.00 °C	Min Temp: 0.00 °C				
Device Status:	On: Device Off	Defrost: Defrost Off	Defrost Pause: Defrost P...			
	Keyboard: Keyboard Unlocked	Energy Saving: Energy Saving Off	STP: STP OFF			
	Superheating Not Avail: Superh...	Press. Not Avail: Press. Not Avail	RegTimeOutAfterDef: Re...			
	Fan Delay: Fan Delay OFF					
Digital Input:	Generic Digital Input1: Dig Input...	Generic Digital Input2: Dig Input...	Generic Digital Input3: Di...			
Device Outputs:	Defrost: Defrost OFF	Alarm: Alarm OFF	Light: Light OFF			
	Fan: Fan OFF	Aux: Aux OFF	Compressor: Compresso...			
						9
282.24						
279.36						
276.48						
273.60						
[°C] Probe 1						

Above, an example of alarm notification with a PDF file, included as an attachment in the new alarm notification mail.

- List of controllers

The list of configured controllers is always present on the left-hand side of the screen. Clicking on the lens - as demonstrated below - selects the "Category Settings" tab which displays the list of all variables configured as alarms.



Showing Associated Variables for Device: RS1-100 New_XW760L Show All Variables				
Variable Name ^	Addr	Device	Model	Category
Cooling	RS1-100	RS1-100 New_XW760L	XW760L	Default
EEPROM Failure	RS1-100	RS1-100 New_XW760L	XW760L	None
Error Pb1	RS1-100	RS1-100 New_XW760L	XW760L	Default
Error Pb2	RS1-100	RS1-100 New_XW760L	XW760L	None
Error Pb3	RS1-100	RS1-100 New_XW760L	XW760L	None
High Value Pb1	RS1-100	RS1-100 New_XW760L	XW760L	Default
Low Value Pb1	RS1-100	RS1-100 New_XW760L	XW760L	None
NoLink	RS1-100	RS1-100 New_XW760L	XW760L	Default
Open Door	RS1-100	RS1-100 New_XW760L	XW760L	Default
RTC Failure	RS1-100	RS1-100 New_XW760L	XW760L	Default

The buttons are also present on the left-hand side of the window.


1. "Clone Alarm Settings" for copying between instruments of the same alarm-category settings.
2. "Save Configuration" to apply any modifications. **Attention:** the save operation must be performed each time the tab is changed otherwise any modifications will be lost.

On the right-hand side of the window are three different tabs identifying the below described configuration parameters.

- Alarm-Category Parameters Tab

The Alarm-Categories is a list of types of alarm, with the purpose of grouping the alarms that must be dealt with in the same manner, from a point of view concerning alarm detection and their notification.


For example, it is possible to create a category named "Temperature Alarms" or "Pressure Alarms"; and associate all alarms of this type with the above-mentioned alarm-categories.



Access the tab in order to scroll down the list of configured alarm-categories. Each alarm-category displays a list of notification levels (as demonstrated above).

- press "+" to add a new category.
- modify the category by pressing 
- eliminate the category by pressing 
- to display the configured alarms for the category, press 


Category parameters:



- **Name:** identifies the category itself;
- **Delay:** stand-by time for the processing of the alarm, from when it is read by the controller network to when it is effectively considered an alarm: if the alarm is resolved before this time runs out, the source of the alarm is ignored. This parameter is useful for the delayed management of the "open door" status which comes from an I/O board: the variable is not an alarm but with the XWEB-EVO it can be used as if it were.
- **Accumulation time to alarm reset:** the system sends notification when the alarm is reset. However, the system waits for the resetting of other alarms for the period indicated in this parameter, before sending a cumulative notification. This therefore reduces the notification line's task; relieving it of any critical conditions such as is the case when the line is slow (e.g. fax line). This parameter works similarly to the "Accumulation" time present amongst the "alarm notification parameters": However, in the case of the alarm-categories, the time is divided between all of the "Alarm Level Settings";
- **Alarm-Level Settings:** notification level. The order is important: the first level to be notified (entry level) is that with the lowest number ("Setting 1"). The up-scaling of the notification level occurs based on the parameters set in "Settings".
- **Alarm types, quick configuration (optional):** list of all types of alarms recognisable in the configured devices. The sole selection of the types does not change the alarm-category configuration. But on the contrary, prepares the category for the receipt of these alarms the next time the User assigns a device to the same category. Example: having configured the category with a "High Temperature" alarm, drag a list of controllers and drop into the same category: this assigns the "High Temperature" alarm for all devices in the list for the category.

- Level Parameter Tab

The alarm notification parameters identify the notification levels. Each level includes the users who receive the alarm notifications.



- press "+" to add a new level
- to modify the level parameters press 
- to eliminate the level press 

Some parameters must be set for each "Setting":

New Setting

Setting Name:

☒ Notify on Start
☒ Notify on End
☒ Send Single Notification


Accumulation Time (min):
Resend Time (min):
Resend TTL (min):

Service Activation:
☐ AUX2 ☐ AUX3 ☐ Printer ☐ XCenter Notification
☐ RAUX1 ☐ RAUX2 ☐ RAUX3 ☐ RAUX4

Name	FAX	FAX OCR	EMAIL	EMAIL IMG	EMAIL ATT	SMS
Admin	☐	☐	☐	☐	☐	☐
luca	☐	☐	☐	☐	☐	☐

Email/Fax Header:
Calendar:

- **Setting Name:** identifies the notification level
- {166Notify on Start167}: enabled for the sending of new alarm notifications
- **Notify on End:** enabled for the sending of alarm-over notifications
- **Send Single Notification:** the enabling of this parameter invalidates the accumulation time. If the system detects two alarms simultaneously, the users will receive two separate notifications.
- **Accumulation Time:** the time during which the system awaits the detection of new alarms for the sending of a cumulative notification
- **Re-send Time:** interval between notifications of persisting alarms. For example, if a new alarm message is sent but ignored or lost, the system notifies the same message again after the indicated time. This parameter is critical to "level" climb logic: if this parameter value is 0 after the first notification, the level is scaled upwards
- **Resend TTL:** maximum time within which the continuously active alarm is notified of the current level rules. After this time, the level is up-scaled to the next level indicated in the alarm-category.
- **Service Activation:**
 1. AUX2/AUX3: the alarm notification occurs by means of the local relay, physically present on rear of the XWEB-EVO machine. The configuration parameters of this relay are available on page "Menu→XWEB SYSTEM SETUP→System Setup→AUX Outputs". Warning: on XWEB300D/500D/500 models the names AUX2/AUX3 are named AUX1/AUX2
 2. RAUX1/ RAUX2/ RAUX3/RAUX4: the alarm notification occurs by means of the remote relay physically present on an XJR40D controller connected to the Modbus network. The relay parameters of this controller are available on page "Menu→XWEB SYSTEM SETUP→System Setup→AUX Outputs"
 3. PRINTER: the alarm notification occurs by means of the local printer physically connected/configured to the XWEB-EVO. The configuration parameters of this printer are available on page "Menu→XWEB SYSTEM SETUP→System Setup→Printers"
 4. XCENTER: the alarm notification is sent to the Dixell XCenter system. Configure the system by accessing the page "Menu→XWEB SYSTEM SETUP→System Setup→XCenter"
 5. FAX: the alarm notification is performed through means of a fax message being sent over the telephone line
 6. FAX OCR: the alarm notification is performed by means of a fax message being sent over the telephone line in a fixed-width font format and therefore automatically segmented
 7. EMAIL: the alarm notification is performed by means of an email message being sent as demonstrated below




The HTML part is the format rendered by the browser. The text is better suited to automatic parser and is as follows.

```
Content-Type: text/plain; charset="UTF-8"
Content-Transfer-Encoding: 8bit

Alarm Report: XWEBEVO Xweb EVO system name|XWEB EVO system description
START|18/10/2013 17:26|RS1-007 New_XR170Cxxxxx|Low Value Pb1
```

The text is common to all other email formats.

8. EMAIL IMG: the alarm notification is performed by means of the sending of a message, in which the body constitutes an image. The format is as follows:



9. EMAIL ATT: the alarm notification is performed by means of the sending of an email message with a PDF file attached and containing the same information as the EMAIL IMG.

10. SMS: the alarm notification is performed by means of the sending of an SMS message.

- **Email/Fax header:** customised text entered in the subject field of emails and faxes.
- **Calendar:** filter calendar on alarm notifications; the calendar identifies the period during which the notification messages will not be issued

Calendar:

luca holiday



calendars are set on the system with present in TOOLS.

All email formats can be analysed by automatic robots examining the section "text/plain".
Below is an example of an alarm email:

```
Thread-Topic: Alarm(s) Notification - XWEB EVO XWEB EVO
Content-Type: multipart/alternative; boundary="-----=_NextPart_001_00dbelc4.5236b
```

This is a multi-part message in MIME format.

```
-----=_NextPart_001_00dbelc4.5236b6ac
Content-Type: text/plain
```

```
Report Allarmi: XWEBEVO Xweb EVO|XWEB EVO START|13/09/2013 17:34|RS1-040
New_XC1008D|No-Link
Device      Model Alarm name Started      Ended Term.
RS1-040 New_XC1008D  XC1008D      No-Link      13/09/2013 17:34
```

```
-----=_NextPart_001_00dbelc4.5236b6ac
Content-Type: text/html
```

```
<!DOCTYPE html PUBLIC "-//W3C//DTD XHTML 1.1//EN" "http://www.w3.org/TR/xhtml11/D
```

- Tab System Alarms

System Alarms

☐ Alarm on Blackout Return
☐ Alarm on High CPU Temp
☐ Alarm on Historical HD Full
☐ Alarm on Log HD Full
☐ Alarm on Temporary HD Full
☐ Alarm on Email Send Error
☐ Alarm on FAX Send Error

☐ Alarm on SMS Send Error
☐ Alarm on XCenter Trap Error
☐ Alarm on Printing Error
☐ Alarm for Digital Input 1 State
☐ Alarm for Digital Input 2 State
☐ Alarm for System Configuration error

Receivers:

☐ Enable AUX1 management

Name ^	FAX	FAX OCR	FAX INFO	EMAIL	EMAIL ATT	EMAIL INFO	SMS
Admin	☐	☐	☐	☐	☐	☐	☐
luca	☐	☐	☐	☐	☐	☐	☐

Enable system alarms that must be managed by the system, with notification i.e. via email.
The messages sent by the system are of the same type as those managed by "system messages"
By selecting "Email" + "EMAIL INFO" for the sending, you select the extended email format demonstrated in the image below. The email in the mail client appears as (Outlook 2007):

Xweb EVO nome sistema

Evento messaggio di sistema

Informazioni di sistema:

Data/Ora: Tue Oct 1 17:39:00 2013
Sistema acceso da: 5 Ore 54 Minuti
Temperatura Cpu: 86.87 °C
Carico medio della Cpu: 0.44 0.43 0.37
Spazio usato nel disco storico: 3%
Spazio usato nel disco log: 5%
Spazio usato nel disco temporaneo: 1%
Memoria totale disponibile: 1619 Mib
Memoria utilizzata: 25.92%
Stato acquisizioni: ON da 5 Ore 50 Minuti
Stato relay allarme: OFF da 5 Ore 51 Minuti
Stato relay Aux 2: OFF da 5 Ore 51 Minuti
Stato relay Aux 3: OFF da 5 Ore 51 Minuti
Velocità ventola rack: Basso velocità da 0 Ore 0 Minuti
Dispositivi a setup: 11 Totali 11 Abilitati
Allarmi dispositivi: 3 Totali 3 Modificati
Errori notifiche: 0 0 0 0 0 (mail/fax/sms/print/snmp)
Tempo di ciclo acquisizione: RS485_1: 1 Minuti 7 Secondi (175.48 122 S)
Ingresso digitale 1: -
Ingresso digitale 2: -

The same email in text format can be segmented and the most significant information highlighted in yellow:

Date: Tue, 1 Oct 2013 15:38:58 +0000
To: <xyz>
From: Xweb EVO system name <example@domain.com>
Subject: Caution: Cpu HT / Stp

MIME-Version: 1.0
Content-Type: multipart/alternative; boundary="-----EVO40DFF36D5A44ECBC"
Return-Path: example@domain.com
X-OriginalArrivalTime: 01 Oct 2013 15:38:57.0073 (UTC) FILETIME=[5774E210:01CEBEB3]

-----EVO40DFF36D5A44ECBC
Content-Type: text/plain; charset="utf8"
Content-Transfer-Encoding: 8bit

IP:10.100.81.208
GATEWAY:10.100.81.1
EXTERNAL-IP:10.100.81.208
DNS1:10.100.80.20
DNS2:

-----EVO40DFF36D5A44ECBC

Diminutives errors, of subject

Acq OFF The acquisitions are stopped.
Cpu HT High temperature of CPU
Ist LS History disc space almost exhausted
Log LS Log disc space almost exhausted
Tmp LS Temporary disc space almost exhausted.
Eml Email sending errors
Fax Fax sending errors
Sms SMS sending errors
Prn Print errors
Trap Trap to xcenter sending errors
Di1 Error from digital input 1
Di2 Error from digital input 2
BlackOut Return from blackout error
Stp Evo configuration error.


Other information

IP: => IP address.
GATEWAY: => Network gateway address.
EXTERNAL-IP: => (coincides with EVO IP)
DNS1: => First dns
DNS2: => Second dns


- Tab Reports

This window enables the User to verify the alarm configuration from certain reports. Select the filter identifying the report and press "Apply Filter".


- Device alarm list, not associated with any alarm-categories



- List of alarms for User



- Full configuration



3.4.7 STOP/START ACQUISITION

The XWEB-EVO principally identifies two mutually exclusive statuses:


1. Acquisitions stopped. This status allows for the configuration of the basic machine parameters. For example, it provides the user with the necessary access to configure parameters relative to the system or to the controller network configuration. This status does not allow for monitoring or supervision. Therefore, the controller alarms cannot be detected and notified.
2. Acquisitions active. This status enables the configured machine to establish constant communication with the instrument network and, consequently, allows for monitoring and supervision. Attention: this status must be enabled at the end of the machine's configuration by the installer.

The status of the acquisitions is displayed on the navigation bar, so it can be identified by the user on each XWEB-EVO page.

Acquisitions active: 

Acquisitions inactive: 

Access MENU→ACQUISITIONS→**Start Acquisition** to start the acquisitions



Access MENU→ACQUISITIONS →**Stop Acquisition** to stop the acquisitions.

3.4.8 SYSTEM VERSION/UPDATE



Access the menu “XWEB System Setup→System Update” to access the update control panel. This window displays all updates already applied, and it is possible to check if there are further updates present. Depending on the system configuration, there will be three keys for installing new updates:

- Repository. For remote installation via internet connection. As configured in section “XWEB System Setup→System Setup→Updates”.
- Usb. For local patch installation via USB key.
- Upload. For remote installation with uploading of update file from web-browser

3.4.9 REBOOT



Access the menu “XWEB System Setup→Reboot” to reboot the machine software. Rebooting is useful to qualified personnel only, such as the customer support team.

3.4.10 SHUTDOWN




Access the menu “XWEB System Setup→Shutdown” for machine shutdown. Shut down is useful to qualified personnel only. **!!Attention!!** This operation is not reversible, so when the machine has been switched off, it will not switch on again until the machine is powered or the switch-on button is pressed. We recommend disabling this operation for users accessing the system remotely. Rebooting is useful to qualified personnel only, such as the customer support team.


3.4.11 LAYOUT SETUP MODE (ONLY FOR MODELS 500D/500 AND 3000/5000)



Access the menu “XWEB System Setup→Layout Setup Mode” to create customised desktops with graphic widgets made available by the system.




The user populates the desktop with widgets via drag'n'drop from the palette accessed by pressing "Menu". The procedure requires the user to hold down the left key of the mouse over the desired widget, i.e. "image", and to then drag it onto the work area for positioning. Once the widget is in place, proceed with dimensioning and configuration. The latter must always be performed by pressing the "wrench" key.




The page - different for each type of widget - which defines the subject parameters, opens when the wrench key is pressed.

The supported widgets are:


- Rectangle




- Image




- Pie chart



- Gauge



- Thermometer




- Global Commands




- Mini Device View

New_XR570C	
Room (Pb1)	6.2 °C
Set Point	3.0 °C
Alarm	OFF
Defrost	OFF

- Device Variable




- Digital Input



3.5 MENU TOOLS

The XWEB-EVO allows for the use of different tools for device programmatic management. To access these tool pages, open MENU and select TOOLS as demonstrated below.




Many of the functions in this menu require the use of a virtual machine JAVA. Refer to the last pages of this manual for certificate management ("6.11 HOW TO MANAGE THE JAVA CERTIFICATES").


3.5.1 SCHEDULER (ONLY FOR XWEB500D/500/3000/5000 MODELS)



With this powerful tool, it is possible to quickly and efficiently manage the sending of repetitive commands to the tools. Commands are, for example, the sending of commands to switch on or to switch off lights or to schedule periodical defrosting. The graphic display aids the management of the single commands. To run the "Scheduler" access the menu "TOOLS" and then press "Scheduler". The following window will appear:



The following image shows an example of the operational and configured scheduler



The complete daily range (from 00:00 to 24:00) is shown at the base of the window. Each hour is marked with a vertical placeholder.

- Setting saving

Access the menu item Save to save the configuration. Attention, once you save it is no longer possible to recover a previous version.


- Print scheduler configuration

Access the menu item Settings→Print to launch printing in local on your web-browser. For example:




- Scheduler configuration export

Access the menu item Settings→Export to file to export the Scheduler configuration in a TXT file. When selecting this menu, you will be asked to indicate the path and name of the file to be saved. We recommend saving the file with .txt extension (e.g. “scheduler_xweb.txt”).




- SCHEDULER Enabling

For the unconditional enabling of the scheduler, access the menu Settings→Enable Settings.




To completely disable the scheduler, access the menu File and untick any item enabling the same scheduler.



The scheduler may also be enabled and disabled from a digital input. The enabling/disabling logic is set by ticking one of the items of “Enable Scheduler via DI X Y” where X can be 1 or 2 and Y can be Open/Close.

- Creation/setting of classes for the events


Access the menu Settings→Classes→New Class to create new classes or Settings→Classes→name to modify those already existing.



Fill in "Class Name" and select a type of device. Select all tools to be associated with the operations of the device class. For example, to send a command to the devices or to run other types of operations as described below.

- Creation/setting of command events to devices

To send commands to time, create the event by clicking the (+) button on the desired class instruments.



Each event corresponds to sending a command of network controllers to one or more devices.


The 'Event' dialog box is shown with the following settings:

- Name: my Event
- Time: 14:00
- Mark: Romboid
- Color: Yellow
- Enabled: ☒
- Add to All Days: ☐
- Type: Command Event
- Command: Active Defrost

Buttons: Cancel, Add

- Creation/setting of report events

To create a timed report, access the menu Events→Add Printing Event to create a new event. The event reports are normally used as HACCP automatic reports. Each event corresponds to the creation of a report and to its sending through means of one of the system configured media (printer, fax, email).



The report is created starting with the selected variables; select them one at a time or use the quick selection filter (Fast Selection).

The 'Event' dialog box is shown with the following settings:

- Name: my Event
- Time: 14:00
- Mark: Romboid
- Color: Yellow
- Enabled: ☒
- Add to All Days: ☐
- Type: Printing Event
- Variables: Select Variables
- Printout Name: printout name
- Print Labels: ☒
- Source: Archive
- Back Int. (h): 24
- Interval (min): 15
- Extended: ☒
- Headers: this is my report!
- Footer Text:
- E-Mail: ☒
- Export Attachment: CSV
- Receiver: Select Receivers

Buttons: Cancel, Add


Activation Time: time the report is created.

Marker colour: marker colour of the event on the scheduler (only for printer  / ).

Add Event to All Days: assignment of the event to all days created in the calendar.


Printout Name: name of report used in the header (only for real time report/print).

There are two types of created report: real time or archive. The first takes a "photo" of the situation regarding the tools at a certain time. As illustrated in the image below.




The second takes a "photo" of the situation regarding the tools from the time of the event and up to 48 hours prior its occurrence. We can have two types of representation:

- Not-extended:



- Extended: refers to the representation of data with one column per variable. When reading the data in the column, refer to the number in the header list which identifies the variable.




“Print copies” to print on local printer, configured on xweb.

FAX for sending the report via fax configured on xweb.

Email for forwarding via email, with report in email or as attachment.


- Creation/setting of system message events




To send system messages, click on (+) button.

The system events live connected solely to class “XWEB System Events”, which cannot be removed.

The system events live



The system events are issued to the recipients and media configured in Settings→System Events



- Creating/setting of events generating historical data Excel files

The XWEB-EVO is able to create historical data excel files. There is a 48 hour limit from when the event first occurred. To configure this option, access the menu Event→Add Export Event.


Select the class on which to connect to the event.

Select the variables for the report.

Set the server parameters on which to create the Excel file containing the report data:

The protocols available are: FTP/SFTP/SCP. A password is required to connect to the server receiving the Excel files. For the correct "server", "port" settings, etc., we recommend seeking support from your network administrator. The Server-Address must be a valid IP. The Server-Path must be a valid path, alphanumeric, delimited with "/" (e.g.: "myPath/mySubPath"). The path on which to create the file must exist. If the path does not exist, XWEB will attempt to create it, but the directory creation command must be enabled on the receiving Server-Address for the selected protocol. The Branch-Code must be an alphanumeric string.

Once configured, the Excel files will be created as: <PATH>/<BRANCH>-<datetime>.XLS as per screenshot below.



The format of the files is as demonstrated below, where each Excel worksheet is dedicated to a single device.

	A	B	C	D	E	F	G	H	I	K	R	S	V	W	X
1	Date-Time	Room (Pb1)	Evaporator (Pb2)	Set Point	On	Defrost	Keyboard	Energy Saving	Low Value Pb1	Error Pb1	No Link	Defrost	Cooling	Door Switch	Generic Alarm
2	28/11/2011 10:44	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
3	28/11/2011 10:59	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
4	28/11/2011 11:15	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
5	28/11/2011 11:30	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
6	28/11/2011 11:45	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
7	28/11/2011 12:00	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
8	28/11/2011 12:15	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
9	28/11/2011 12:30	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
10	28/11/2011 12:45	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
11	28/11/2011 13:00	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
12	28/11/2011 13:15	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
13	28/11/2011 13:30	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
14	28/11/2011 13:45	-6,70	-25,50	2,00	ACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	DEACTIVE	ACTIVE	DEACTIVE
15															

001 fakeDeviceName

002 New_XR570C



004 New_XR70CX

005 New_XR170C

007 New_XR170C

- Change/deletion of events


Click on the event: the list of all events at that time configured will open, as demonstrated below.




To delete, once the event is selected click.

- Using the calendar in scheduler


By default, for all calendar days, the system uses the "type of day" (Default Day). When configuring the scheduler for the first time, this day is that proposed by the system for configuration.



To create a new type of day click on Settings→Days



Other types of days can be created and then associated on the calendar. The scheduler will then perform the associated events, for the associated days.



For example, you may have configured special events for the weekend and your calendar may appear as illustrated below, with the (type of) weekend day associated for public holidays.



To create a new (type of) day, access the menu “Edit Days→New day definition”. The system requests the configuration of the following image window parameters

It is necessary to indicate the name of the (type of) day, e.g. "weekend", and give it a colour for recognition. The colour will be important for visual recognition on the calendar.

The "Enabled" parameter indicates whether the events configured on the day are active. The "Yearly" parameter indicates whether the day is to be associated - to all years - for operations of association to calendar. Attention: once the day has been created, the "Yearly" parameter can no longer be modified.

To modify the existing day types, select the day to be modified from the menu Days→and then access the menu “Edit Days→Modify Current Day...”. To delete the current day, access the menu “Edit Days→Delete Day”.


To associate the days on the calendar, access the menu “Edit Days→Calendar Association”. To associate the days, click on the day and select the (type of) day desired. It is also possible to associate the (type of) day on week days by clicking the name in the red band, e.g. apply the day "weekend" to all Sundays.

To configure the previously created (type of) day, access the menu Days and select the day.

Note that the classes are common to all types of day. But that each day defines its specific events.

- Display options

Access the menu “Show Logs” to show logs of the scheduler



Access the menu “Windows→Show Calendar” to show the calendar.

Access the menu “Windows→Show Logs” to show the scheduler logs, for the list of sent commands and other actions performed.

Access the menu “Windows→Show Commands/Printing/System Events/Export Events” to show/hide events for the current day.

3.5.2 DEVICE LINE TEST



Click on menu “TOOLS→Devices Line Test” to access the test page of the communication with the setup devices.

Device	Success(%) ^	Time Out(%)	Exception(%)	Crc error(%)	Overrun(%)	Unknown respons(%)
RS1-100 New_XC1015D	0.00	100.00	0.00	0.00	0.00	0.00
RS1-110 New_XH55P	0.00	100.00	0.00	0.00	0.00	0.00
RS1-200 New_ICHILL	0.00	100.00	0.00	0.00	0.00	0.00
RS1-5 New_XR170C	95.83	0.00	4.17	0.00	0.00	0.00
RS1-7 New_XR170C	95.83	0.00	4.17	0.00	0.00	0.00
RS1-2	96.00	0.00	4.00	0.00	0.00	0.00

Device to be tested: RS1-002 Test cycles: 10

Buttons: Start test, Reload media, Reset device transaction status, Selected, All

Access to the window shows the statistics table on the communication with the configured tools. Each device has been represented in columns:

- Device: device name
- Success(%): successful communication total percentage
- Time Out(%): errors for Time Out percentage. This type of error occurs in cases in which the device is switched off or not reachable
- Exception(%): errors for exception percentage. This type of error occurs when the device is reachable, but there are inconsistencies between the configuration of its parameters and that shown on the XWEB-EVO
- Crc-Error(%): CRC error percentage. This type of error occurs when the device can be reached, but there are problems on the line such as interferences.
- Overrun(%): percentage errors for packages in transit but not expected. This type of error occurs when the device can be reached, but there are problems on the line such as interferences.

- Unknown(%): percentage of others detected, different from those reported in previous rows.
Example: equality or other errors.

The table enables sorting by column. It is advisable to press "Success(%)" to easily identify the addresses of the most problematic devices.

The table does not automatically refresh but it can be manually updated by pressing "Reload media".

The statistics can be reset with the keys "Selected" and "All".

Identification of device configuration errors:

Should a tool show exception errors, it is possible to ask the system to run a new specific test for the tool, so that it detects the most problematic sizes. The following example demonstrates the identification of a tool with a certain percentage of exceptions, but no other type of communication error:

Device	Success(%)	Time Out(%)	Exception(%)	Crc error(%)	Overrun(%)	Unknown respons(%)
RST-3 New_XR70CA	100.00	0.00	0.00	0.00	0.00	0.00
RS1-5 New_XR170C	95.83	0.00	4.17	0.00	0.00	0.00

It is selected to execute the test. The "test cycle" value identifies the number of readings that will be carried out for each device resource.

Device to be tested

Test cycles

RS1-005 New_XR170C

10

Start test

After having pressed "Start test", the configured variable that does not respond is displayed, i.e. Pb3 which is not enabled by the tool parameters.

Test result						
Total transactions	Success	Time Out	Exception	Crc error	Overrun	Unknown respons
110	100	0	10	0	0	0
Results in detail						
Variable	Success	Time Out	Exception	Crc error	Overrun	Unknown respons
Error Pb3	0	0	10	0	0	0
Defrost	10	0	0	0	0	0
Set Point	10	0	0	0	0	0
Door Switch	10	0	0	0	0	0
Generic Alarm	10	0	0	0	0	0
Defrost	10	0	0	0	0	0

3.5.3 PERFORMANCE MANAGER (ONLY FOR 500D/500/3000/5000)



Performance Manager (or Performance Meter) is a tool for the analysis and verification of the correct dimensioning of the plant, utility control, operating statistics.

To execute this procedure, configure a device class and finalise the calculation indicating the time range on which it is to be applied.

- Tool class configuration

Create the device class for which the calculation is to be carried out: access the menu "Class→Create Class" and indicate the parameters of:

- **Class name:** name of class
- **Devices of class:** enable devices that must be part of the class. The list of devices is displayed according to the filter "Typology Filter", which helps to display only the devices belonging to a certain group.
- **SetPoint:** select the set-point variable. The unit of measure depends on the chosen variable.
- **Probe:** select the probe variable connected to the set-point. The unit of measure depends on the chosen variable.
- **Normal Range:** select the normal range of the probe value. The unit of measure is the same as that of the probe variable.
- **Defrost Offset:** select the time after defrosting, for which the Probe value is not considered in calculating the %Cool. In minutes
- **Sampling:** sampling period of data requested by the server during calculation. If, for example, you configure sampling at 1 hour (60 min), requesting data from the last 2 days, the system sends 48 pieces of "data" (1 sample per hour). As this parameter value increases, the data to be sent by the system will be reduced. This is the ideal condition for using this tool with a slow or busy telephone network. The value of this parameter is used as the 'default' value and can be changed in the calculation (window Performance→View Class)
- **Avg.Factor:** number of transactions represented for the samples sent to server. The system averages this number of consecutive samples. For example, with the 48 pieces of data returned by the server as in the above example, if you were to set this value at 1: at a graphic level there will be up to 48 possible transactions of various colours low/ok/high, assuming that the data is all within a different range. While, if the average value is 4, there will be a maximum of 12 colour transactions (averages at 4 hours of data). This parameter has the function of avoiding out-of-range temporary values, which do not affect the calculation or the graphic representation. The value of this parameter is used as a "default" value and can be changed in the calculation (window Performance→View Class)

The Select/Deselect All keys are for a quick selection of all displayed devices.

The Create/Cancel keys are for creating the class and saving it in the system. Or to cancel any modifications and close the window.

- Execution of calculation and presentation of the result

Access the menu "Performance→View Class" to perform the calculations with graphic representation. The system asks the user to define some parameters:

View Class

Select a Device Class and Query Type

Class: test class

☒ Circular Data Interval

☐ Main Data Interval

Sampling (min): 3.0

From: / / : / /

To: 18 / 06 / 13 15 : 20

Sampling (min): 3.0

Avg.Factor 5

Show Cancel

- **Class:** class of tools to be calculated
- **Circular/Main Data Interval:** select the source of data from the XWEB history. The circular data defined as data, the sampling frequency of which is the highest possible for the system, is limited in time to the last two days of sampling; the main data is that which has a frequency defined by the recording parameter in "device setup" usually at 15 minutes.
- **Sampling:** the Sampling value set in the class is taken as the default value. Here, it can be modified to perform the calculation
- **Avg.Factor.** The Avg.factor value set in the class is taken as the default value. Here, it can be modified to perform the calculation

The Cancel key closes the window without performing any calculation. The "Show" key performs the calculation and shows the results as demonstrated by the example below:

Xweb EVO		Probe: Room (Pb1)					Normal Range:		Legenda		
Class: test class		Period: 16/06/2013 15:45 - 17/06/2013 18:21					-6.0 ... 8.0 °C		(On Mouse Over)		
Device Name		SP	Avg	Min	Max	TDef	% Cool				
RS1-002 New_XR570C		0.0	-20.2	-21.5	0.0	0.0	===				

Various clicks

Project Class Performance

Xweb EVO

Probe: Room (Pb1)

Class: test class

Period: 11/06/2013 11:16 - 18/06/2013 16:33

Device Name	SP	Avg	Min	Max	TDef	% Cool
RS1-002 New_XR570C	0.0	-21.5	-21.5	-21.5	-21.5	===

click

Alarms for RS1-002 New_XR570C

Description	Start Time	End Time
Open Door	11/06/2013 11:03	11/06/2013 11:06
Open Door	11/06/2013 11:06	11/06/2013 13:23
Open Door	11/06/2013 17:42	12/06/2013 10:24
Open Door	12/06/2013 10:25	12/06/2013 10:25
Open Door	12/06/2013 10:26	12/06/2013 10:29
Open Door	12/06/2013 10:32	12/06/2013 11:11
Open Door	12/06/2013 11:13	12/06/2013 12:25
Open Door	12/06/2013 12:25	12/06/2013 12:25

Close

Probe: Room (Pb1)

Period: 11/06/2013 11:16 - 18/06/2013 16:33

SP	Avg	Min	Max	TDef	% Cool
0.0	-21.5	-21.5	-21.5	-21.5	===

Min at: 11/06/2013 11:16




MOUSE-OVER

Period: 11/06/2013 11:16 - 18/06/2013 16:33


Min	Max	TDef	% Cool
-21.5	-21.5	-21.5	===

Max at: 11/06/2013 11:16


MOUSE-OVER




“Performance→Data ScreenShot”



“Performance→Export To Text File”






3.5.4 COMPRESSOR RACK OPTIMISER (C.R.O., ONLY 500/5000 MODELS)




C.R.O. works with a proprietary algorithm developed by Dixell that combines the complexity of the cooling system with the simplicity of the parameters that the user must set at a program level. It works on two basic parameters to guarantee the best possible adjustment of the refrigerator: the suction pressure of the compressor plant (detected by a series XC1000D ver.1.1 or higher controller) and the more critical utility from a "consumption of cold" point of view.

Depending on the model of your XWEB-EVO, the function may have a different number of CRO engines. The following types of parameters are common for all. A window such as that illustrated below appears when the CRO menu is opened for the first time.




- Utility Configuration

Create a new class of utilities to use the C.R.O.. The data required to operate the project is extracted from these controllers. Open the "Class" menu and create a class including the utilities of interest. Utilities are those with the saturation pressure set-point in common.



Use the Create/Edit/Delete menu items to modify the utility classes. Each utility class can and must be assigned to one of the CRO engines. The use of the same class applied to multiple engines is not permitted.

Access the menu Operation→Parameters Engine relative to the desired CRO engine to set the configuration parameters. The C.R.O. module, to better manage the availability of cooling power, in time, modifies the set-point of the compressor plant (typically, for utilities in normal temperature mode).



Parameters

Engine Parameters 1

Engine is: **ACTIVE**

Execution Interval (min): 240

Back Analysis Interval (min): 60

Regulation Parameters

Reference Class: all devices ▼

Controller: RS2-010 New_XC1011D ▼

Set Point: SupVis set SUC1 ▼

Worst Case Set: 90 (%Cool)

Dead Band: 4 (%)

Initial Set Value: -35 (°C)

Min Set Value: -38 (°C)

Max Set Value: -30 (°C)

Release Gain: 20 (m°C / %Cool)

Call Gain: 50 (m°C / %Cool)

Post-Defrost Timeout: 5

Simulation Mode: ☐ Acquire Data Only

Cycling Mode: ☐ ON Time 0 (hours)

Enable Engine **Disable Engine** **Close**


- **Execution interval:** indicates how often a new set-point is sent to the plant (in minutes).
- **Analysis interval:** indicates for how many minutes, in reverse, the data is to be analysed (operation of class utilities; in minutes).
- **Reference class:** is the set of controllers affected by the calculation of the worst possible case.
- **Device:** is the plant controller affected by the modification of the set-point.
- **Set-Point:** allows you to select which set-point to use: typically, that of the plant suction section.

- **Worst case threshold:** allows for the defining of the intervention threshold for the C.R.P. algorithm (in %)
- **Neutral zone:** specifies an oscillation band (centred on the percentage of the worst possible case) inside which the algorithm does not intervene.
- **Initial value:** initial set-point value. The value can be an estimate: in time, the set-point value sent to the plant will change -according to the algorithm (typically in °C).
- **Min. and Max. Set-points:** safety limit values associated with the minimum and maximum suction pressure: to prevent C.R.O. from excessively increasing or lowering the pressure to avoid the safety devices from triggering. (typically in °C). It is good for the minimum value to be as high as possible in order to optimise energy consumption.
- **Release and Call Gain:** the call and release gain are two parameters that decide by how much the current set-point must be increased/decreased. The call-gain parameter is used should the set-point need to be decreased. It is useful to set a higher call-gain value than the release-gain in order to quickly decrease the temperature (typically in m°C/%).
- **Post Defrost Time out:** the duration after a defrosting event that is ignored in calculating the percentage (in minutes).
- **Simulation Mode:** The enabling of simulation mode does not send the set-point values calculated by the algorithm
- **Cycling Mode:** The enabling of cycling mode, combined with cycle time (in hours) continuously enables and disables the algorithm. This mode is useful for checking the quality, when applied to the system. Usually, cycle times of no more than three days are set. When the algorithm is disabled, a reset command is sent to the plant for its repositioning to its initial state.

Typically, the units of measure of the plant are expressed in °C, however, C.R.O. adapts to the plant's unit of measure. However, should the unit of measure be modified in the next phase, it will be necessary to re-configure the CRO starting with the disabling of the set-point variable from the algorithm parameters, subsequently re-configuring the unit of measure in "Devices Setup" and re-configuring the CRO parameters.



Calculation



Should the real percentage of the worst possible case be below that set (except the neutral zone), the formula used for the new set-point is:

$$Set_{new} = Set_{old} + \Delta\% \cdot \left(\frac{RLS_{gain}}{1000} \right)$$

$\Delta\%$ = (calculated percentage value) - (percentage set for the worst possible case)

RLS_{gain} = release-gain parameter value

And vice-versa, should it be above the set percentage (except the neutral zone), the formula used for the new set-point is:

$$Set_{new} = Set_{old} - \Delta\% \cdot \left(\frac{CALL_{gain}}{1000} \right)$$

$\Delta\%$ = (calculated percentage value) - (percentage set for the worst possible case)

$CALL_{gain}$ = call-gain parameter value


The calculated percentage refers to the analysis range and it changes from time to time based on the real system conditions.

Each engine must be activated by pressing enable system. To deactivate it, press disable system. The engine status is displayed at the top of the window.

Engine Parameters 1	Engine Parameters 1
Engine is: ACTIVE	Engine is: STOPPED

- CRO results with graphs

To display the status of the three worst utilities, from the cold call point of view, open the menu Operation→View Data.




Select the class and then the devices for which the report is to be issued. The three devices considered to be the worst in the latest period, will be shown on the screen (as illustrated by the image below). The worst device is that indicated in the red column.

Risultati richiesta freddo (TN)											
Calc. Time	Dispositivo 1	On/Off	Ch.	Dispositivo 2	On/Off	Ch.	Dispositivo 3	On/Off	Ch.	Set	
31/05/2013 12:30	040 5TN Carni	100.00%	1	030 2TN M Murale S/L	76.66%	13	042 22TN Carni	74.48%	4	-8.22	
31/05/2013 12:23	040 5TN Carni	88.87%	2	030 2TN M Murale S/L	74.45%	13	042 22TN Carni	73.37%	5	-6.95	
31/05/2013 12:16	040 5TN Carni	83.32%	4	030 2TN M Murale S/L	73.34%	13	042 22TN Carni	60.06%	6	-6.51	
31/05/2013 12:09	030 2TN M Murale S/L	76.70%	15	040 5TN Carni	69.97%	5	032 2TN S Murale S/L	57.77%	10	-6.51	
31/05/2013 12:02	030 2TN M Murale S/L	75.58%	13	040 5TN Carni	65.52%	6	036 3TN S Murale S/L	58.90%	10	-6.73	
31/05/2013 11:55	030 2TN M Murale S/L	75.59%	13	040 5TN Carni	56.62%	7	042 22TN Carni	52.29%	8	-6.99	
31/05/2013 11:48	030 2TN M Murale S/L	75.58%	14	036 3TN S Murale S/L	52.20%	10	040 5TN Carni	46.61%	8	-7.25	
31/05/2013 11:41	030 2TN M Murale S/L	71.12%	15	036 3TN S Murale S/L	54.42%	11	040 5TN Carni	47.74%	8	-7.51	
31/05/2013 11:34	030 2TN M Murale S/L	71.11%	14	036 3TN S Murale S/L	57.75%	11	040 5TN Carni	47.78%	9	-7.92	
31/05/2013 11:26	030 2TN M Murale S/L	74.45%	13	040 5TN Carni	53.33%	8	036 3TN S Murale S/L	51.09%	11	-8.34	
31/05/2013 11:19	030 2TN M Murale S/L	74.44%	13	040 5TN Carni	51.15%	9	036 3TN S Murale S/L	46.69%	12	-8.64	
31/05/2013 11:12	030 2TN M Murale S/L	74.44%	13	036 3TN S Murale S/L	54.46%	11	040 5TN Carni	51.17%	9	-8.94	
31/05/2013 11:05	030 2TN M Murale S/L	74.44%	13	040 5TN Carni	54.51%	7	036 3TN S Murale S/L	54.46%	11	-9.24	
31/05/2013 10:58	030 2TN M Murale S/L	75.55%	13	040 5TN Carni	63.37%	7	036 3TN S Murale S/L	54.46%	11	-9.54	
31/05/2013 10:51	030 2TN M Murale S/L	76.63%	13	040 5TN Carni	73.37%	5	042 22TN Carni	66.68%	5	-9.80	
31/05/2013 10:44	030 2TN M Murale S/L	79.95%	11	040 5TN Carni	74.47%	3	042 22TN Carni	71.11%	3	-10.02	
31/05/2013 10:37	040 5TN Carni	86.69%	3	042 22TN Carni	83.32%	3	030 2TN M Murale S/L	83.28%	9	-10.13	
31/05/2013 10:30	040 5TN Carni	96.67%	1	042 22TN Carni	96.67%	1	030 2TN M Murale S/L	86.64%	8	-9.85	
31/05/2013 10:23	040 5TN Carni	100.00%	1	042 22TN Carni	97.78%	2	030 2TN M Murale S/L	86.65%	9	-8.83	
31/05/2013 10:16	040 5TN Carni	100.00%	1	042 22TN Carni	83.36%	3	030 2TN M Murale S/L	83.28%	8	-7.55	
31/05/2013 10:09	040 5TN Carni	86.68%	3	030 2TN M Murale S/L	83.31%	9	042 22TN Carni	81.13%	4	-6.28	
31/05/2013 10:02	040 5TN Carni	78.91%	4	030 2TN M Murale S/L	76.66%	11	042 22TN Carni	67.81%	5	-6.00	
31/05/2013 09:55	040 5TN Carni	74.44%	5	030 2TN M Murale S/L	70.00%	13	036 3TN S Murale S/L	62.15%	9	-6.00	
31/05/2013 09:48	030 2TN M Murale S/L	66.68%	15	040 5TN Carni	61.09%	6	036 3TN S Murale S/L	61.06%	11	-6.25	
31/05/2013 09:41	030 2TN M Murale S/L	63.34%	16	036 3TN S Murale S/L	58.86%	10	040 5TN Carni	55.53%	8	-6.82	
31/05/2013 09:34	030 2TN M Murale S/L	64.46%	14	036 3TN S Murale S/L	56.66%	10	049 11TN Cella ortofrutta	53.37%	8	-7.51	
31/05/2013 09:27	030 2TN M Murale S/L	64.50%	17	049 11TN Cella ortofrutta	60.02%	12	036 3TN S Murale S/L	57.80%	11	-8.16	
31/05/2013 09:20	030 2TN M Murale S/L	68.93%	15	042 22TN Carni	66.72%	5	040 5TN Carni	62.17%	5	-8.81	
31/05/2013 09:13	030 2TN M Murale S/L	74.48%	15	040 5TN Carni	73.30%	5	042 22TN Carni	71.15%	3	-9.30	
31/05/2013 09:06	042 22TN Carni	83.36%	3	040 5TN Carni	79.96%	3	030 2TN M Murale S/L	74.48%	15	-9.60	
31/05/2013 08:59	042 22TN Carni	92.23%	1	040 5TN Carni	86.65%	3	030 2TN M Murale S/L	74.45%	16	-9.60	
31/05/2013 08:52	040 5TN Carni	100.00%	1	042 22TN Carni	85.54%	2	030 2TN M Murale S/L	75.55%	15	-8.91	

For each device, in addition to its name, the amount of cold call is also indicated. "Ch." corresponds to the compressor start-ups, while "On/Off" corresponds to the call of the eventual electronic expansion valve. These values are used to calculate the cold call percentage of the algorithm. Each line corresponds to a different moment in which the C.R.O. algorithm has sent a new set-point to the plant: this set-point is shown on the right, below the "Set" column.

From the previously described window, press "Graph Results" for a graph displaying the same information. The user is asked to indicate the graphic tools with which to display the graph.



The graph shows the collected data for the selected period; together with the plant set-point as a dotted line. With C.R.O. deactivated, the central set-point would be a horizontal line: the areas above this fixed set-point and floating set-point are energy saving.

The plant set-point is illustrated in the first graph of the following image, whilst in the graph below, the energy consumptions relating to the same period are shown.



3.5.5 DEW POINT MANAGEMENT (SOLO XWEB5000)



The Dew-Point managing concept enables the XWEB-EVO to act on the adjustment of the anti-sweat heaters in order to reduce their electricity consumption.

The XWEB-EVO acts on the XM600 controllers, to which the Dew-point temperature set-point is sent. Condensation builds up on the controlled bench window surrounding the system. These controllers are defined in the configuration of a class. Each engine can manage a class. Each engine may relate to different zones of the system where work is to be carried out with different settings and parameters.

All of the following configurations are part of the dew-point project that will be run by the system if at least one of the dew-point engines is activated.

- Class Configuration

To create a class, access the menu “Class→Create Class”.

Please Check Carefully the Device Classes

Class Name: XM600 DEWPOINT

Typology Filter: All

☐ RS1-002 New_XR570C	Set Point	0.00
☐ RS1-003 New_XR70CX	SetPoint	0.00
☐ RS1-005 New_XR170C	Set Point	0.00
☐ RS1-007 New_XR170C	Set Point	0.00
☐ RS1-010 New_XC1015D	Set point SUC1	0.00
☐ RS1-020 New_XH55P	Set Point	0.00
☐ RS1-025 New_XM670K		0.00
☒ RS1-026 New_XM679K	Set Dew Point	3

Select All Deselect All

Create Cancel

Class Name: class name used in the configuration of the dew-point engine.

Typology Filter: filter allowing for the display of only the chosen device list.

For each device represented in the list, it is defined:

- Check enabled: defines whether or not the device is part of the class
- Set Dew Variable: defines the variable towards which the dew-point value will be sent. Attention: if the Set Dew Point variable is not visible in the list, it has probably been disabled by the tool advances. Access Device-Setup→Advances and enabling.
- Offset: value added to the Set Dew value. Reflects the difference between the temperature read by the XM600 probe that is not normally fitted on the glass and the real glass temperature.

To modify an existing class, access the menu “Class→Edit Class”

To eliminate an existing class, access the menu “Class→Remove Class”.

With keys:


- Select/Deselect All: select/deselect all devices in the list, combining them with the class
- Create: to confirm the parameters entered in the window and create the class
- Cancel: to close the window without confirming the entered parameters
 - Dew-point Engine Configuration

Access the menu Operation→Engine Parameters X representing the Dew-point management engine number to be run

Operation

- Engine Parameters 1
- Engine Parameters 2
- Engine Parameters 3
- Engine Parameters 4
- Engine Parameters 5


Each of these engines can be configured with the following parameters:



- Execution Interval: cycle time for sending the dew-point set (in minutes)
- Destination Class: class of devices receiving the dew-point set value
- Control Device: device for calculating the dew-point set value. Should the XH50/55P box be selected, the calculation is performed by the same device that must be specified with field "XH50/55P Device". This controller is connected to a temperature and humidity probe in the room. Should this device not be available, it is possible for the XWEB-EVO to calculate the Dew-point Set value, by specifying the variables from which the room temperature and humidity values are to be read. They are indicated with parameters Temperature/Humidity controller and Temperature/Humidity Input.
- Constant Set Offset: offset at Dew-point set value added
- Min./Max. Set: limit values of Dew-point set. Should these values be higher or lower, they are sent to the controller of the class configured for this engine

With keys:

- Enable/Disable Engine: it enables/disables the dew-point engine. Visual feedback is provided on the engine's state on the top part of the window, as demonstrated below.



- Close: it closes the window, saving any modifications applied to the parameters. Attention: the modifications made to the parameters must be saved on the system before being applied by the system itself. To save, run the save operation of the project (of dew-point)
- Cancel: it closes the window, cancelling any modifications applied to the parameters
 - Project saving (of Dew-point)

All dew-point management parameters are part of the same project. Every time a parameter is modified, for it to be applied to the system, run the project save operation by accessing the menu Project→Save

- Control of the project log (of Dew-point)

ERRORS:

Lists the possible errors that the system can send to the "Result" column

"Valid" => in the value column, the value calculated and sent to the central device is shown.

"Syntax error" => There is an error in the formula defined by the user. The mathematics is not developed.

"No device data" => There is no data from the device and the mathematics cannot be developed.

"No link device" => As above, since the device is a NoLink

"Device OFF" => As above, since the device is in Off mode.

"Math div by 0" => The mathematics development is stopped due to a division by "0"

"Value not allowed" => The values for the formula variables are not permitted (out of range)

"Mathematic" appears in the "Device" column

The possible errors that may occur when sending the set to the central device include:

"Timeout" => No response from device.

"Exception" => Value not accepted by device.

"Unknown" => Unknown error.

"Success" => Value sent with success.

The device name/address is shown in the "device" column.

3.5.6 XWEB5000 SUPERVISOR SYSTEM (ONLY XWEB5000)



The supervision concept significantly expands the possibility of intervention by the XWEB5000 on system management. Supervision is intended as the ability of independent intervention by the monitoring unit on the monitored devices. To simplify the concept, it may help to think of a functional block with all the variables detected on the controller field (temperatures, pressures, operating status, alarms, etc...) as an input, and as an output, the possibility of sending specific commands to the same controllers. The basic link between input and output lies in the supervision, that is to say, in a special algorithm that the user has programmed and that the system implements each time the input variables meet the set criteria. Pay due attention to the fact that the sending of certain commands verified, following the establishing of certain input conditions, is not accompanied by the sending of additional commands when the input conditions fail. In other words, when the user considers and realises the direct action, the reverse action must then be realised. Otherwise, the system is unable to restore the initial conditions when required.

Given the evident importance of this new work tool, Dixell has tried to make its usage as simple as possible for the end-user. This is why the event is programmed through the graphic user interface, therefore, no programming knowledge is required (in contrast with what occurs with normal programming languages for PLC).

THE PROJECT

From a practical point of view, the user must be familiar with the supervision project to be realised in advance, this is why, for educational purposes, the project considered throughout this chapter will be the following:

the installation in question, demonstrates the need to monitor the operating state of an emergency generator that is only activated should there be no electric energy supply. Upon the occurrence of this condition, the supervisor must send a series of commands to the utilities in order to manage, at the highest possible level, the energy saving function during a power-cut. In the example in question, the generator is monitored through means of a Dixell XJA50D controller (alarm/status acquisition module): when the generator is activated, the module signals this through the variation of the corresponding digital input. During operation with an emergency generator, the XWEB-EVO must send the "energy saving" command (variation of work set-point) and, only for the compatible utilities as well as the "save cold" curtain lowering command.

SDC, ELS and ODC

Each project consists of at least 3 distinct blocks:

- SDC (source device class) is the set of controllers whose variables (probe values, operating state, etc...) constitute the inputs for the supervision project.
- ELS (event logic supervisor) is the functional block that combines the input performed by the SDC with the output, that is to say, the sending of the commands to the supervision project controllers.
- ODC (object device class) is the class of tools involved by the sending of commands

Other blocks can be associated with these functional blocks, e.g. STE (system time event) as well as others that will be added by Dixell during the development of the XWEB5000 project.

SDC BLOCK

Choose the "Create" menu. We will create a SDC that verifies the state of the XJP30D module digital input. When this input is active for at least 3 minutes, the generator is to be considered active.

Enter an appropriate name under "SDC name". From the device type filter, select the tool to be monitored. Go to "activation" and in our example select "Generic digital input".

If multiple variables and devices are configured for this block, the logic rule constructed by the above parameters corresponds to:

OUTPUT = ((RL 'VarA'-Addr₁) ACT (RL 'VarB'-Addr₁)) DL
((RL 'VarA'-Addr₂) ACT (RL 'VarB'-Addr₂)) DL
((RL 'VarA'-Addr₃) ACT (RL 'VarB'-Addr₃)))

Where

RL = Revers logic (box selected = not)

ACT = Activation logic. AND or OR

DL = Device Logic. AND or OR.

'VarA'-Addr₁ = Variable A of device address 1.

If the control must be executed on numeric values, set the condition (greater, less, equal) and the corresponding threshold value.

The block output results from the above calculation. Value 0 corresponds to status DIS (disable). Value 1 corresponds to status ENA (enabled). These front changes are sent to the next block (ELS), which will then carry out further processing and act by sending commands to the successive blocks.



The ENA status can be activated with a delay, set with parameter DELAY. The above assumed logic continues to always be met and returns the TRUE value. The block status, from the moment in which the logic is met at the end of the delay time, assumes the DLY value.



The ENA status can be maintained with a maximum time set with parameter DURATION. After this time, the block status switches from ENA to DUR.



ODC BLOCK

Choose the "Create" menu. We will create an ODC that sends the reduced set-point command. The normal work set is increased by a few degrees by this command and is sent to 2 walls.

Enter an appropriate name under "ODC name". From the device type filter, select the category to be monitored. Select the tools and go to "available commands". In our example we have activated the "energy saving ON" command.

Fill in the "ODS Active Label" and the "ODS Not Active Label". These labels are used should you decide to assign a "Monitoring type" rule that enables the XWEB-EVO system to recognise the effective sending of the command.

The screenshot shows the "Object Device Class (ODC)" configuration window. It contains the following fields and options:

- ODC Name:** Energy Saving ON
- Device Tipology Filter:** All
- Device List:**
 - ☐ RS1-003 New_XR70CX
 - ☐ RS1-005 New_XR170C
 - ☒ RS1-007 New_XR170C
 - ☐ RS1-050 New_XW70L
- Buttons:** Select All, Deselect All
- Available Commands:**
 - ☐ Alarm Mute
 - ☒ Energy saving ON
 - ☐ Energy saving OFF
 - ☐ Aux ON
- Available Set Points:**
 - ☐ Set Point
- ODS Active Label:** Energy Saving Activated
- ODS Not Active Label:** Energy saving not active
- Monitoring Type:** OR, Digital State
- Monitoring Rules:**
 - ☐ Defrost, ☐ NOT, User Label
 - ☐ Keyboard, ☐ NOT, User Label
 - ☒ Energy Saving, ☒ NOT, User Label
- Notes:** (Empty text area)
- Buttons:** Modify, Cancel

The possibility of entering notes that can be subsequently used to understand the meaning of the logic block being created can be very useful.

ELS BLOCK

Choose the "Create" menu. We will create an ELS that ties the two blocks so far realised. The ELS acts as a filter combining the input (generator status) and the output (command sending to utilities).

Enter an appropriate name under "ELS name". This block allows for the linking of the SDCs to the ODSs.

The user can create multiple functional blocks, linking only those used for the project in question. The other blocks can be used in other projects.

Event Logic Supervisor (ELS) ...

ELS Name: Energy save mng

Available SDC:

☐ Power Supply Status RV AND

☐ Power Supply Status GA AND

☒ Power Supply Status OR

Available STE:

☐ STE 01 AND

Available ODC:

☐ Energy Saving OFF

☒ Energy Saving ON

Available EMM:


Notes:

Modify Cancel

This block can be configured with multiple inputs, such as SDC and/or STE blocks. A logic group can be associated with each of these: AND/OR/DIS. The rule that is executed is $(\sum \text{And} \mid \sum \text{Or}) \& \sum \text{!Dis}$ where
And=AND logic of all parameters in AND;
Or=OR logic of all parameters in OR;
Dis=NOT logic of all parameters in DIS.
Example with C=Condition of Input (SDC/STE):

C1 AND
C2 OR
C3 AND
C4 OR
C5 AND
C6 DIS
C7 DIS


The resulting logic is: $((C1 \& C3 \& C5) \mid C2 \mid C4) \& !C7 \& !C6$



The logic configured for each input is shown on the project screen as a label on the same inputs. As illustrated in the above image.

Complete project

The complete project is displayed by means of the macroblocks:



Press "Note" on all blocks to view what is written during the block realisation phase.

Press "On/Off" on ELM block to enable/disable the block execution.

Right click with the mouse on all blocks to modify the selected block. Or duplicate it.




STE BLOCK


This logic block allows for the management of the timed events. It is a programmable filter, the status of which can be added to the project and linked to the ELS block. It is useful to set night/day filters or hourly filters.

When the input conditions (from the SDC block) occur, the system also checks the STE status. In view of this verification, ELS is activated. Should this occur in vice-versa the event in ODC will not run.

The STE blocks correspond to the "classes" configured in "Supervision Time Event". Access from menu "Tools→Manage Supervision Time Event (STE)".




Different STE blocks can be created from the menu "STE Management".




For each of which, you can add a band from the menu


For the removal or modification of the band times, move the red/green triangles (red=band end, green=band start) or click with the mouse on the triangle to open the editing menu of the band itself.



The bands created for the various STE blocks can vary by calendar. It is possible to create time bands linked to a "type of day" and then associate this to the calendar.



The above images show that the bands differ between "default Day" and "holiday". The first "type of day" is used for all standard days of the year, while "holiday" is to be associated with, for example, December 25th. To do this, use the calendar by accessing the menu "Edit Days→Calendar Association".



EMM BLOCK

The EMM block can receive alarms or notifications

With the EMM block you can receive alarms or notifications regarding the status of the active supervising programs.

The list of receivers depends on the receiver book filled in the ALARM configuration. The message text is the content of the fax/mail that you intend to send. The EMM also report information regarding the status of the controller that will usually correspond to the controller modified by the ODC action or the SDC enabling condition. The EMM block will be added after the ELS. This means that once the SDC is enabled and the ELS activates, the ODC and the EMM will send a message according to the setting selected.

Event Message Manager (EMM)	
EMM Name:	emm
☐ Alarm Event	☒ Notification
Receivers:	
Admin	☐ FAX ☐ EMail
luca	☐ FAX ☒ EMail
Message Text:	
the fan has been activated!	
Device Report Data	
Device Tipology Filter:	XR570C
☒ RS1-002	
Select All Deselect All	
Monitoring Type:	Digital Output
☐ Defrost	User Label
☐ Alarm	User Label
☒ Fan	User Label
Notes:	
notes	
Modify Cancel	

PROJECT SIMULATION

Once the project is realised, it can be partially or totally simulated before being considered definitive. There are 3 types of simulation: Local test, on-field Simulation and Runtime mode.

LOCAL TEST

This mode is useful when a rough idea of what happens when varying the status of the inputs is necessary. Access the menu "Tools" and then "Local test".

When this mode is selected, the system removes the ODS block as the simulation does NOT provide for the sending of any command - neither written nor read - to the tools.

The status of the SDCs can be forced by clicking their status. A block which in turn activates the ELS. The chain interrupts on block ODC, which simulates the command sending but does not in fact realise it.




In the above image, we clicked on the SDC block when in status DIS: block enabling activates block ELS which then turns red. And the ODC block sends a false command.

Select "Modification mode" from the "Tools" menu to return to modification mode.

ON-FIELD SIMULATION

The input statuses can be forced through means of this test in order to produce and verify the sending of the commands to the utilities. Pay attention to the fact that this test sends commands to the utilities, it is not a simulation, however the results are real and reflect the system response. To force the inputs statuses, place the mouse pointer on block SDC or STE and right-click to activate the "Disconnected inputs" mode. The user can now force the status of an input by left-clicking the mouse on the corresponding item "ENA" (enabled) or "DIS" (disabled). Based on the programming performed, the ELS block will pass the command sending the request to the next ODC. Be careful when exiting the on-field test mode, the system returns to the previous project conditions and sends commands to utilities, if necessary. Therefore, consider the potential sending of additional commands before abandoning the project.



RUNTIME MODE

This mode allows the user to verify, in real time, the status of the system operation following the execution of a supervision project. The user cannot, in any way, interact with the project. ATTENTION: each time runtime mode is engaged, the system is put into its working position which is, at that moment, decided by the SDC status. When runtime mode is deactivated, the system is reset. This may entail the sending of an additional command.

ACTIVATION of projects


The system allows for the simultaneous execution of multiple projects, the user must then decide which to activate. From the menu "Projects", "Project activation", select the project to be activated via the appropriate check box.

VISUAL FEEDBACK

Once the supervision program is running, it provides the user with important information in graphic form. The following table summarises the possible work situations.

Logic block	value/colour	description
SDC	ENA/green	on
	DIS/grey	not active
	DLY/grey green	awaiting deadline of activation delay
	DUR/blue	active and awaiting deadline of duration
STE	ENA/green	on
	DIS/grey	not active
ELS	red background	on
	green background	not active
ODC	SENT/yellow	command sending
ODS	???	status unknown
	Act	active for digital conditions
	NotAct	not active for digital conditions
	Set	if all sets are the same and the control occurs on a set-point
	NEQ	different set values and the control occurs on a set-point

3.5.7 BACKUP/RESTORE



This procedure allows the user to save the system data and/or restore it if required. It is possible to create a backup on the XWEB memory or on the hard disc of the client's PC as well as on storage devices connected via USB. Attention: the USB devices used for restore-backup, must only be inserted before starting such procedures and disconnected when these have been completed. The restore procedure overwrites data memorised on the XWEB. This means that restoring a backup returns the XWEB status to that present on the date when the

backup was performed. When clicking on the icon, the user must select which type of operation is to be completed:




The backup and restore procedures can be run on partial xweb data, such as:

- EVO system configuration. Basic configuration of XWEB machine
- Operating configuration. Configuration of controllers, Alarms, Scheduler, other
- Alarm/System logs.
- Main historical data.

Backup


The procedure allows for the saving of data selected in "Sections", on the device selected in "Destination".



The most thorough backup is run by selecting all items in "Sections". Press "Start backup" to complete the operation.

Restore

The procedure allows for the recovering of data in the XWEB memory.



The user must select the backup data source to be restored: The “Evo system backup disk” allows for the uploading of a backup previously run in the XWEB memory; The “Usb connected to evo” enables the recovery of data from the USB device and “Upload backup” allows for the remote uploading of a backup with the browser.

Once the data source has been selected, select the data to be recovered from "Section". Press "Start restore" to complete the operation.

3.5.8 DAILY EXPORT



Daily export

This procedure allows for the configuring of the XWEB so that it creates a new datalog file on a daily basis that can always be recovered from an external server with an HTTP call.



The user must indicate:

- the **variables** for which the history is desired. Select them by clicking with mouse. The selected variables are indicated by the colour yellow. For a quick configuration. the user can use the options in "fast selection"
- enable the service
 - or on demand. for copying data to the insertion of the USB stick
 - or export at time: to update the data exported by HTTP call. The time update
- Export from: start time of the data to be exported
- Record interval: filter that identifies the minimum period between the samples that will be exported from the system
- Format CVS / EXCEL

Once configured, the user must confirm by pressing APPLY.

To recover the data: connect with the syntax:

http://IP_EVO/getdailydata?g=1?u=<username>?p=<md5 password>

Evo transmits a zip file with the name "export_xls_YYYYMMGGhhmm.zip" or "export_csv_YYYYMMGGhhmm.zip".

For example:

export_xls_201311271234.zip (for xls export)


export_csv_201311271234.zip (for csv export)

In case that you have done the export of USB, the files will be copied to the same as in the image below

Name	Type	Compressed size	Password p...	Size	Ratio	Date modified
RS1_001_New_XR570C.csv	Microsoft Excel Comma S...	26 KB	No	650 KB	97%	13/04/2015 11:55
RS1_002_New_XR170C.csv	Microsoft Excel Comma S...	24 KB	No	683 KB	97%	13/04/2015 11:55
RS1_003_New_XR170C.csv	Microsoft Excel Comma S...	24 KB	No	642 KB	97%	13/04/2015 11:55
RS1_004_New_XR70CX.csv	Microsoft Excel Comma S...	24 KB	No	708 KB	97%	13/04/2015 11:55

In case the data were exported as a CSV note that the conventions applied are:

- Comma, separator columns
- Point, as decimal separator



- Giorno/Mese/Anno

Text Import Wizard - Step 3 of 3

This screen lets you select each column and set the Data Format.

Column data format

☐ General
☐ Text
☒ Date: DMY
☐ Do not import column (skip)

'General' converts numeric values to numbers, date values to dates, and all remaining values to text.


Advanced...

Data preview

DMY	General	General	General	General	General	General
	RS1_2 New_XR170C					
	Room (Pb1) °C	Evaporator (Pb2 °C	Set Point °C	On	Defrost Ke	
07/04/2015 15:35:00	-10.80	-7.00	-25.00	1	0	0
07/04/2015 15:36:00	-10.80	-7.00	-25.00	1	0	0
07/04/2015 15:37:00	-10.80	-7.00	-25.00	1	0	0
07/04/2015 15:38:00	-10.80	-7.00	-25.00	1	0	0

Cancel < Back Next > Finish

3.5.9 CALENDAR SETUP



Accessing this option allows for the management of the calendars that can be used by the system.

Calendar Setup

Calendars Available:
days off: [dropdown]
Save Save As... Delete

Default Event Times
Default Start: 09:00
Default End: 21:00
Add New Event

Fast Movement:
December 2013
Report... Time Report...

January 2014

Sun	Mon	Tue	Wed	Thu	Fri	Sat
01-09:00-21:00 days off (Weekly)						02-09:00-21:00 days off (Weekly)
05-09:00-21:00 days off (Weekly)	04	05	06	07	08	09-09:00-21:00 days off (Weekly)
12-09:00-21:00 days off (Weekly)	13	14	15	16	17	18-09:00-21:00 days off (Weekly)
19-09:00-21:00 days off (Weekly)	20	21	22	23	24	25-09:00-21:00 days off (Weekly)
26-09:00-21:00 days off (Weekly)	27	28	29	30	31	03-09:00-21:00 days off (Weekly)
06-09:00-21:00 days off (Weekly)						10-09:00-21:00 days off (Weekly)

For the selected calendar, the user adds event periods by clicking on the same calendar or on the "Add New Event" key.

Add New Event

Event Name: New Event

☒ Weekly
☐ Sunday ☐ Monday ☐ Tuesday
☐ Wednesday ☐ Thursday ☐ Friday
☐ Saturday

From: 09:00 To: 21:00

☒ Absolute
 From: 20/12/2013 10:34 To: 20/12/2013 10:34
☐ Yearly


Cancel Add

The user must set the period name and interval as well as the period.

3.5.10 DATA LOG STATUS



Data Log Status Access to this option allows you to monitor the amount of data stored in XWEB




- a. Log: memory used
- b. First Date: date oldest sample recorded in permanent memory
- c. Last Date: date most recent sample recorded in permanent memory
- d. Approximate Log Duration: approximate date when the oldest data will be deleted
- e. Registration Time: sampling time (polling) on the serial.

3.5.11 RUNTIME DATA




Runtime Data Access to this option allows you to monitor the overall status of the system. The selection the user has to select the group of tools which want to monitor the status, from the drop-down menu in the top left corner.




The devices in alarm have a red background, as the first image above.

From this window you can also send commands to the selected instruments. To select just click on their area and selected when an arrow to the left of the device is presented as in the image below.



On selected instruments you can send the command from the button 'Commands' at the top right. From which the user must select the command from the pulldown menu.



If more tools have been selected, the curtain will populate the only controls that are common to all instruments.

3.5.12 LANGUAGES MANAGER



Access to the panel of language management allows the user to manage the languages that are managed in the system. Factory system presents the user with the following languages:

1. English
2. Italian
3. Spanish
4. German
5. Portuguese
6. Russian

Other languages can be added / removed and the translations are handled with Excel files.

The system with hardware that mounts software production version 2.0 from the factory, operates a total of up to 10 languages. Additional installed languages can reduce the duration of data storage temperature less than one year.

Add New Language

For the addition of a new language specify


1. A language already present in the system to inherit translations
2. Name of the language in format acronym. The box to the left indicates the language and the right side shows the country for the management of the dialect
3. Name of the language in extended format

Export Language

Exporting is the preliminary step to the translation. Select

1. The translation of the source language (eg English)
2. The language that you want to do the translation (eg Japanese)

Xweb export an Excel file containing all strings in English and Chinese. Strings in China will not be translated but will probably be changed by the translator.



Import Language

To import the system of translation. The format should be that of the Excel spreadsheet.

Clone Language

To copy the translation from one language to another.

Remove language


To remove a language.

3.6 DESKTOPS

The desktops represent the main tasks that the XWE-EVO provides its users.

3.6.1 DESKTOP OVERVIEW

The "Overview" desktop is the desktop that appears to the user just after login. This desktop provides the user with an overview of the status of the network tools and allows for the execution of procedures such as sending global commands (e.g. lights switch-on/off) and HACCP print




- Setup controllers

Each configured device is represented by a box coloured according to the status of the device itself. The devices are automatically grouped in sections according to the group configuration.

Colour	Meaning
Green	No detected alarm
Red	Alarm
White	Acquisitions Off
Orange	No-link status

Move the mouse cursor over the device of interest. A pop-up opens providing the device name and other information.



Click on the device box to open the "Device View" desktop which provides the complete details of the device of interest.

- Active alarms table


The "Active Alarms" section represents the list of active alarms, in real time, relating to the configured controls.

The list of alarms can use filters, visible and configurable, on the first line of the table.

Active Alarms								
Code	Name	Category	Start	Device Name	Addr.	Note	NTF	
15	Open Door	Default	14/05/13 00:25:09	New_XR170C	R51-007			
14	Low Value Pb1	Default	14/05/13 00:25:07	New_XR570C	R51-002			


- HACCP Print Configuration (ONLY FOR 500/3000/5000 MODELS)

The "HACCP Print" key must be configured before being able to execute printing operations. Therefore, the user performing the configuration must access the configuration menu by clicking on the wrench icon as demonstrated below.




The configuration window opens after clicking on the configuration key enabling you to indicate:

1. the temperature variables. By selecting the corresponding filter. Press "Add" to create a filter



And select the desired variables by naming the filter.



Filter

temperatures

Add... Delete... Edit...

Filter Preview

Addr/002	New_XR570C	Room (Pb1)	°C
Addr/003	New_XR70CX	Probe 1	°C
Addr/005	New_XR170C	Room (Pb1)	°C
Addr/007	New_XR170C	Room (Pb1)	°C

2. the default time that will appear to the user during printing

Default Interval

☐ Runtime
 ☒ Last Week

☐ Today
 ☐ Last 24h

☐ Yesterday
 ☐ Last 48h

The user who intends to print can also alter the time during the printing operation.

3. the type of output

- download browser: for opening the file in the browser. The browser must have a plug-in for PDF files
- print on XWEB Default Printer: for printing using the configured printer in the menu→xweb system setup→System Setup→Printers
- send Email to: for sending emails. A mail server must be configured from the menu→xweb system setup→Email
 - HACCP Print Execution

The “HACCP Print” key allows for the printing or the sending of the HACCP report. The following window appears when the key is pressed: the user is asked to modify, if necessary, and confirm the period for which the report is required.

HACCP Event

Output

☐ Runtime
 ☒ Last Week

☐ Today
 ☐ Last 24h

☐ Yesterday
 ☐ Last 48h


From: 12/05/2013 16:38
 To: 13/05/2013 16:38

Output Type: Filter Name:haccp
Browser Download




Cancel Ok

The output type represents a configuration summary of the report.

- Global Command Configuration



- Global Command Execution




- Configuration for "HACCP Print" action.

3.6.2 DESKTOP DEVICE VIEW


The "Device View" desktop provides the user with all the resources monitored by the selected device. All variables monitored by the field will be listed, including the

- analogue variables. Set-points and analogue I/O: probe values or from analogue outputs (e.g. output 0-20mA)
- digital variables. Machine statuses, digital I/O, alarms. For example, "stand-by" status, digital input and high temperature alarm.

3.6.2.1 SELECTION OF DEVICE



Use the "device category" filter to help choose the device of interest: selecting the category limits the available devices. Then, by selecting the desired device, the page is updated, providing the user with information on that same device. It is also possible to browse the device using the keys "< >": they are used to navigate to the nearest Modbus address device.



Selecting a device displays:


- the variables grouped by group of pertinence (Analogue/Status/Alarm etc..). section "deviceView";
- the graph for the device. section "dataChart";
- the list of available commands per device. section "commandButtons";
- list of device parameters. section "parProg"


All page values and relative graphs are updated in real time (on polling time).

3.6.2.2 VARIABLE DISPLAYING


This section shows, for the chosen device, the list of variables to be monitored and their values in real time. The variables are divided between the sections Analogue, State, Set-point, Alarms, Inputs and Outputs. There are two types of display:

- complete: corresponds to the presence of the key "Only active" . All device variables are represented.
- reduced: corresponds to the presence of the "Show all" key ; displaying of the digital variables is limited to those in the "On" status. "On" corresponds to the presence of an alarm for the variables in the "Alarm" section. This mode enables the list to be reduced to show only the variables of interest and facilitate the operator in his/her reading.




The status is shown in blue  for the digital variables, and in red  for the alarm variables only.

In full view mode, it is possible to select or deselect the variables. The selection of each value allows it to be included in the various page elements, such as in the graph shown below.





3.6.2.3 MODIFICATION OF SET-POINT

A set-point can be quickly changed by clicking on its value. The box then goes into edit mode, as demonstrated below.



Enter the new set-point value and press "enter" to confirm. Confirmation of the entered value will be requested before commanding that written by the set-point to the controller.


For each written phrase, the user will be notified as to whether or not the operation was carried out successfully.

Set-point change successful	Set-point change with error
	


To perform this operation, the page must be in full view mode.

3.6.2.4 START FAST ACQUISITION MODEM (FSM)

The FSM mode aims to perform a high speed selective monitoring of the resources for a set time limited to 10 minutes. This type of monitoring allows the user to run the controller debug and/or of its application, as if the other devices were "disconnected" from the tool network. The delay in the acquisition time of the controller values is at a minimum, the device is read more or less in real time.
 Attention: to allow for a higher speed of a controller, the others will be affected. During FSM mode, the sampling time of the other controllers may appear to have increased.
 To run the FSM procedure on a controller, firstly, select the variables of interest from the "device view" section and then press "Start FSM" . When this is pressed, the following message appears requesting confirmation before starting the procedure:



Once confirmed, the user will be warned that the acquisitions have entered in FSM mode for the device.



The FSM mode saves all read samples in the main data archives. All data sampled during FSM mode is marked as such and represented in the graphs by a light-blue background.



3.6.2.5 SENDING COMMANDS TO THE DEVICE


Commands can be manually sent to the selected device, such as "Device OFF", "Device ON", "Active Defrost", etc., via the "Single view" window. To send the command, press the button as demonstrated below:



Confirmation will be requested after which the user is informed whether or not the command was successfully sent.

3.6.2.6 VARIABLE SECTION FOR REAL TIME GRAPH

The graph in the "single view" desktop is a "real time" graph which, by default, shows the "Pb1" variable of the device. The display interval is that of the last three hours.



In this section the user may also wish to view other variables: to add/remove them from the graph, select the variables from the "device view" section during the full view phase.

The graph can be scrolled with the "flag" cursor using your mouse: the "flag" provides the exact value of the variables on the graph itself.

IDENTIFICATION OF THE MINIMUM AND MAXIMUM VALUES IN THE CHARTING PERIOD




They are graphically marked with the coloured dots. The value and date of each of these is also shown.

GRAPH OPTIONS

Click on the wrench icon to access the menu:

- **Settings:** from here, it is possible to change the view interval of the graph itself, and show/hide the minimum/maximum values as well as the background colours



- **Values:** to modify the colour of the graph variables



3.6.2.7 PARAMETER PROGRAMMING


The "parProg" section allows for the management of the parameters associated with the tool operation.

- **Parameter reading**


It is run by pressing "Read". The list of tool parameters is uploaded and the relative values read by the device;

- **Parameter modifying**


After reading, the user can modify the tool parameters. the dump operation of the new parameter values on the tool is executed by clicking on "Write".



- **Save:** saves the parameter map creating a backup. The parameter map can be saved in the XWEB-EVO or downloaded on a PC as a ZIP file, through the browser.



- **Load:** loads the parameter map from a previously saved backup. This loads the map from file or from the XWEB-EVO



- **Export:** to save a ZIP containing the selected parameter map in CSV, PDF, XLS format on PC; or a BIN file compatible with WIZMATE

Device parameters

System name : XwebEvo
 Device : 2 New_XR570C
 Group : All
 Date : 20.03.2013 22:33
 Pages : 2

Index	Description	Label	value	Min	Max	Udm
1	Differential	Hy	4.0	0.1	25.5	°C
2	Minimum set-point	LS	-30.0	-50.0	0.0	°C
3	Maximum set point	US	20.0	0.0	150.0	°C
4	Output delay at power on	odS	0	0	255	min
5	Anti-short cycle delay	Ac	1	0	30	min
6	Fast freezing duration	cct	00:00			
7	Compressor ON with faulty probe	con	15	0	255	min
8	Compressor OFF with faulty probe	coF	30	0	255	min
9	Measuring unit	cF	°C			
10	Resolution	rES	de			
11	Local display	Lod	P1			
12	Defrost type	tdF	rE			
13	Defrost mode : RTC, interval, Smart-def	EdF	In			
14	Set point for smart defrost	SdF	0	-30	30	°C
15	Defrost stop temperature 1st evaporator	dTE	10.0	-50.0	150.0	°C

3.6.3 CHART DESKTOP

The "Chart" desktop allows the user to create a graph with the variables monitored by the XWEB. On accessing the desktop for the first time, the window will appear empty. Afterwards, the graph window appears as it did when the user last logged out.

3.6.3.1 GRAPH CONFIGURATION

Click on the wrench (top-right icon on desktop) to access the configuration window. Here, the user must specify the variables and the time to in order to create a graph. The graph is updated when the display parameters are confirmed.

TAB "SETTINGS"

In this window choose between

Chart Source

- *Main*: this option must be enabled if you wish to create a graph using historical data dating back more than two days
- *Circular*: these archives provide records at the maximum speed on the polling round. But are limited to the last two days only. Choose this option if you wish to debug the system from an alarm notification recently received

Layout

- *Show min./max.:*

the enabling of this parameter allows the user to view the minimum and maximum values that are graphically marked with red dots (for maximum) and blue dots (for minimum). Their values with the date are shown nearby. The minimum and maximum values relate to the time period selected for charting and are real values.



- *Show background:*

Enables background display. If the graph displays data of a single controller, the background colours are

BACKGROUND COLORS: NO-LINK DEVICE-OFF FSM ACQ OFF

If the graph shows data from two or more devices, the information provided by the background colours is:

BACKGROUND COLORS: NO-LINK / DEVICE-OFF / FSM ACQ OFF

- *Enable real time:*


Enables the graph to be displayed in "automatic update" mode. This mode only displays information for the last three hours.

Interval

Select the time range to be charted. If the “enable real time” option is disabled, additional options will appear including "last 24/48 hours; last week; today; yesterday; from/to". The range available will depend on the maximum duration of the sampling


TAB VALUES

In this window, choose the variables that will form the list of those to be used to create a graph. The variable may relate to any tool. From the same, choose the representation colour of each variable.



TEMPLATES

In this window, manage the graph pre-configurations. The display attributes of a graph can be saved and re-used later.



3.6.3.2 READING OF GRAPH



The area of the graph is divided into the following sections:

- A) Axis area (blue): the variables are grouped by axis, for example all temperatures in °C will have the adequate axis and consumptions in Watt will also have an axis.
- B) Analogue variable graph area (green). All analogue variables, even if relating to different controllers, can be viewed on the same area.
- C) Digital variable graph area (purple). All digital variables, even if relating to different controllers, can be viewed on the same area.
- D) Graph overview area (orange). This graph represents the graph total requested from the server and does not consider the zoom factor. This graph can be used as reference for its navigation.

Analogue and digital variables are all included in the same graph, even if coming from different devices.


3.6.3.3 READING THE VALUES OF A PARTICULAR MOMENT

Going over the graph with the mouse shows the moving flag cursor, as demonstrated below. The values of the variables selected at that moment are shown in the flag area.



3.6.3.4 ZOOMING-IN ON AREA

To zoom-in on an area of the graph, click and hold the mouse on a point and drag until the desired area to be zoomed-in on is created.



3.6.3.5 ZOOMING-IN ON AREA OF OVERVIEW GRAPH

To zoom-in on an area of the overview graph, click and hold the mouse on the graph and drag to select the desired area.




3.6.3.6 DATA EXPORT


The graph data can be exported in Excel(R) format. To access this procedure, press "Export" on the configuration window of the graph.



A dialog box appears where the user must set the interval between samples



Upon confirmation by clicking "Ok", the system saves an Excel file on the user's PC.



The content of the file will be similar to that of the following image:

Date-Time											
Time	Probe 1	SetPoint	Cooling	On	Off	High Value Pb1	High Value Pb2				
14:43:20	17,5	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
15:08:03	17,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
15:23:03	17,9	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
15:38:03	18	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
15:53:03	18,1	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
16:08:03	18,2	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
16:23:03	18,3	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
16:38:03	18,4	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
16:56:49	18,6	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
17:11:49	18,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
17:26:49	18,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
17:41:49	18,8	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
17:56:49	18,8	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
18:11:49	18,8	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
18:26:49	18,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
18:41:49	18,3	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
18:56:49	18,1	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
19:11:49	17,9	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
19:26:49	17,8	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
19:41:49	17,6	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
19:56:49	17,4	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
20:11:49	17,2	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
20:26:49	17,1	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
20:42:05	17	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
20:57:05	16,9	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
21:12:05	16,9	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
21:27:06	16,8	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
21:42:06	16,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
21:57:06	16,7	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
22:12:07	16,6	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
22:27:26	16,6	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
22:42:26	16,6	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
22:57:26	16,5	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				
23:12:26	16,5	5	NOT ACTIVE	ACTIVE	NOT ACTIVE	NOT ACTIVE	NOT ACTIVE				

3.6.4 ALARMS DESKTOP

The "Alarms" desktop enables the user to visualise the list of all controller network alarms detected by the system. On the initial access, the alarm list appears with the following default that can be subsequently changed by the user:

The screenshot displays the XWEB system interface for the Alarms Desktop. The main window is titled 'XWEB system' and shows the IP address '10.100.81.183'. The interface is divided into several sections:

- Devices Snapshot:** A panel on the left side, currently empty.
- Alarms Log:** The central section containing filter options and a table of alarms.
 - Alarm Filter:** Includes dropdowns for Level (All), Category (All), and Typology (All), and a Device Filter dropdown.
 - Time Filter:** Includes a 'Last' dropdown set to '3' days, and 'From' and 'To' date/time pickers.
 - User Note Filter:** Includes a 'Users' dropdown set to 'All' and a 'User Notification Filter' dropdown.
 - Apply:** A button to update the alarm list.
 - Alarms List Table:** A table with columns: Code, Name, Category, Start, End, Duration, Terminated, Device Name, Addr., and Not. It shows a list of alarms, with the top row being 'ACTIVE'.
- Alarm Detail:** A panel at the bottom showing details for a selected alarm, including a 'Note' section with a table of user notes and a 'Notifications' section.

The bottom status bar shows 'Logout', 'Time: 20:15', 'Date: 18/04/2013', and a 'Menu' button.

3.6.4.1 ALARM DISPLAY FILTER

The user may use filters to

- **Level.** To visualise only the alarms notified to a specific level. For example 'Service';
- **Alarm-category.** To visualise only the alarms configured with a given category. For example "Serious alarm";
- **Device type** (group). To visualise only the alarms generated by a group of devices. For example "BT".
- **Device name.** To visualise only the alarms generated by a given device. For example 'RS2-005 New_XW90T';
- **Alarm start period.** To visualise only the alarms detected starting from a given period. For example "last 10 days" or "day/y";
- **Note.** To visualise only the alarms with a note entered into the system by a given user.
- **Notification.** To visualise only the alarms notified to a specific user.

Each time the filter is modified, press "Apply" to update the page. The alarm list is generated providing the user with the following information:

Alarms List										
Code	Name	Category	Start	End	Duration	Terminated By	Device Name	Addr.	Not	NTF
28	Open Door	Default	18/04/13 19:51:01	18/04/13 19:54:18	0d/00h/03m/	SELF	New_XR170C	RS1-005	●	
29	Open Door	Default	18/04/13 19:54:51	18/04/13 19:55:07	0d/00h/00m/	SELF	New_XR170C	RS1-005		
30	NoLink	Default	18/04/13 19:55:10	18/04/13 19:57:05	0d/00h/01m/	SELF	New_XR170C	RS1-005		
31	Open Door	Default	18/04/13 19:57:02	18/04/13 19:57:52	0d/00h/00m/	SELF	New_XR170C	RS1-005		
32	Open Door	Default	18/04/13 19:57:58	18/04/13 20:00:21	0d/00h/02m/	SELF	New_XR170C	RS1-005		
33	High Value Pb1	Default	18/04/13 19:58:24	18/04/13 19:58:46	0d/00h/00m/	SELF	New_XR170C	RS1-005		

- **Code:** univocal alarm ID code. This code corresponds to a precise alarm detected at a precise moment.
- **Name:** alarm name
- **Category:** alarm category
- **Start:** date/time when the system detected the alarm. The time delay that may have been configured for managing the same alarm is not considered.
- **End:** date/time when the system detected the alarm reset. Information available only for the resetting of alarms: or ACTIVE if still active.
- **Duration:** duration of alarm. Information available only for the resetting of alarms.
- **Terminated By:** alarm reset.

- "SELF": ALARM RESET INDICATED BY CONTROLLER.
- "NO LINK": ALARM RESET DUE TO FAILED COMMUNICATION BETWEEN THE XWEBEVO AND THE CONTROLLER;
- "SYS STOP": ALARM RESET DUE TO THE INTERRUPTION OF ACQUISITIONS BY THE CONTROLLERS;
- "CONF CHANGE": ALARM RESET FOR ALARM CONFIGURATION CHANGE.

- **Device Name:** name of device to which the alarm refers.
- **Addr.:** address of device to which the alarm refers.
- **Not:** alarm to which notes have been assigned.
- **NTI:** alarm from which notifications were sent.

Usually the data in the table is displayed according to the "Code" value. The primary sort column can be changed by selecting it clicking on the heading; in this case, "Code" will be used as a secondary sort index. Code as primary sorting column:

Alarms List										
Code	Name	Category	Start	End	Duration	Terminated By	Device Name	Addr.	Not	NTF
97	Open Door	Default	18/04/13 22:13:22	ACTIVE			New_XR170C	RS1-007		
96	Open Door	Default	18/04/13 22:13:22	ACTIVE			New_XR170C	RS1-005		
95	Open Door	Default	18/04/13 22:13:11	ACTIVE			New_XR570C	RS1-002		
94	EEPROM Failure	Default	18/04/13 22:09:28	18/04/13 22:10:01	0d/00h/00m/	SELF	New_XR170C	RS1-005		
93	External Alarm	Default	18/04/13 22:09:27	18/04/13 22:10:00	0d/00h/00m/	SELF	New_XR170C	RS1-005		
92	Open Door	Default	18/04/13 22:09:04	18/04/13 22:11:15	0d/00h/02m/	SYS STOP	New_XR170C	RS1-005		

Name as primary sorting column:

Alarms List										
Code	Name	Category	Start	End	Duration	Terminated By	Device Name	Addr.	Not	NTF
96	EEPROM Failure	Default	18/04/13 20:37:40	18/04/13 20:38:19	0d/00h/00m/	SELF	New_XR170C	RS1-005		
94	EEPROM Failure	Default	18/04/13 22:09:28	18/04/13 22:10:01	0d/00h/00m/	SELF	New_XR170C	RS1-005		
83	EEPROM Failure	Default	18/04/13 21:32:25	18/04/13 21:32:52	0d/00h/00m/	SELF	New_XR170C	RS1-005		
71	EEPROM Failure	Default	18/04/13 21:10:02	18/04/13 21:10:53	0d/00h/00m/	SELF	New_XR170C	RS1-005		
17	EEPROM Failure	Default	18/04/13 19:19:15	18/04/13 19:19:54	0d/00h/00m/	SELF	New_XR170C	RS1-005		

3.6.4.2 ALARM LIST EXPORT

Press  to save the Excel file containing the alarm table onto your PC. Example as per the following image:

alarmLog-export-2013_09_29_151900-2013_10_01_151900.xls [Compatibility Mode] - Microsoft Excel

	A	B	C	D	E	F	G	H	I	J	K
	Code	Device Name	Addr.	Name	Category	Start	End	Duration	Terminated By	Notifications:	Notes:
1	1170	New_XC1008D	RS1-040	NoLink	Default	01/10/2013 11:52:58	18/10/2013 16:20:44	17d4h/27m/46s	SYS STOP	lucagmail (01/10/2013 11:53:01) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:53:01) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:53:01) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:53:02) NEW ALARM.EMAIL_OK [first level] lucagmail (01/10/2013 11:52:59) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:53:00) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:53:01) NEW ALARM.EMAIL_OK [first level] lucagmail (01/10/2013 11:48:48) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:48:49) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:48:49) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:44:32) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:44:32) NEW ALARM.EMAIL_OK [first level] lucapic (01/10/2013 11:44:33) NEW ALARM.EMAIL_OK [first level] provueite (01/10/2013 11:44:33) NEW ALARM.EMAIL_OK [first level]	
2	1169	New_ENERG ANAL	RS1-030	NoLink	Default	01/10/2013 11:52:58	18/10/2013 16:20:44	17d4h/27m/46s	SYS STOP		
3	1168	New_XR170Cxxxx	RS1-007	Low Value Pbt1	Default	01/10/2013 11:48:47	18/10/2013 16:20:44	17d4h/31m/57s	SYS STOP		
4	1167	New_XR170Cxxxx	RS1-007	Low Value Pbt1	Default	01/10/2013 11:44:30	01/10/2013 11:47:40	0d0h/3m/10s	SYS STOP		

3.6.4.3 DISPLAY ALARM DETAILS

By clicking on an alarm, the page is updated with new detailed information on the alarm that has just been selected. The "Alarm Detail" section containing the list of notes and the list of users notified of the alarm is updated.

3.6.4.4 READ/WRITE ALARM NOTES

Notes can be added by clicking on "New note:" from the detail of the alarm notes and, in particular, from the "Notes" section.

Alarm Detail
Notes:

User Name	Date-Time	Note
		New Note:

Alarm Detail
Notes:

User Name	Date-Time	Note
		another note
Admin	18/04/13 12:46:00	second note
Admin	18/04/13 12:42:00	this is my first note about the alarm

To save the note, click on the grey area of the same line.

To delete the note, click on the bin icon next to the text of the note.

3.6.4.5 CHECK OF ALARM NOTIFICATIONS

The alarm conditions are normally notified to users of levels for which the alarm is configured. If the alarm persists, the XWEB-EVO system continues to run the notifications. They are recorded in the system and accessible through the "Notifications" section as demonstrated below.


Notifications:					
User Name	Date-Time	As	Media	Status	Level
service	17/06/13 15:00:45	NEW ALARM	EMAIL	OK	service
service	17/06/13 15:03:54	NEW ALARM	EMAIL	OK	service
service	17/06/13 15:05:04	NEW ALARM	EMAIL	OK	director

3.6.5 DESKTOP PARAMETERS

The "Parameters" desktop allows the user to read and modify the parameters of the controllers connected to the device network.

3.6.5.1 PARAMETER READING

Select the device of interest and possibly the specific group of interest of the parameters to be read. Select "Read" from the menu on the right-hand side and run "Execute". The page will be updated with the parameter list. Loading depends on the number of parameters and the connection speed.



ID	Label	Value	Min	Max	Udm	Description
Alarm (11)						
30	dAo	00:00				Temperature alarm delay at power on
35	nPS	0	0	15		Pressure switch activation
26	ALU	5.0	0.0	50.0	°C	High temperature alarm
27	ALL	5.0	0.0	50.0	°C	Low temperature alarm
28	AFH	2.0	0.1	25.5	°C	Differential for alarms
29	ALd	0	0	255	min	Temperature alarms delay
25	ALc	rE				Alarms configuration : relative / absolute
31	EdA	0	0	255	min	Temperature alarm delay after defrost
32	dot	0	0	255	min	Temperature alarm delay after door opening
33	doA	15				Door alarm delay
34	tbA	Yes				Alarm relay reset

The following columns are defined:

Sel: box for selecting the parameters to be exported.

ID: parameter index

Label: parameter description

Value: current value of parameter


Min./Max.: interval of value admitted for the parameter

Udm: unit of measure

Description: description of parameter function

3.6.5.2 PARAMETER WRITING

Select the device of interest and run the parameter reading. Once run, modify the parameter value by accessing the "Value" column.




ID	Label	Value	Min	Max	
Alarm (11)					
30	dAo	00:00			
35	nPS	0	0	15	
26	ALU	6.0	0.0	50.0	°C
27	ALL	5.0	0.0	50.0	°C
28	AFH	2.0	0.1	25.5	°C

Once all parameters of interest are modified, select "Write" and press "Execute". The XWEB-EVO will open the list of all compatible devices on which you can perform "writing". Select those of interest and press "Ok".

3.6.5.3 PARAMETER MAP SAVING

The parameters can be saved on a PC or locally in the XWEB-EVO memory; for use in other installations or for their use at a later date.

Select the device of interest and run the parameter reading. Once executed, press "Save". The XWEB-EVO will open a window requesting where to save the parameter map of the selected device. Select "EVO backup folder" to save in the XWEB-EVO memory or select "Client download" to save the map with your browser. If the map has been saved on a browser, a ZIP file will be downloaded as demonstrated below.



The same file can be reused at a later stage in this or in another XWEB-EVO. Attention: this file cannot be used in previous XWEB versions.

3.6.5.4 PARAMETER MAP LOADING

The parameter map files generated using the above-described procedure can be loaded by selecting "Load" from the action menu and pressing "Execute". The XWEB-EVO will request where to load the parameters: from the XWEB-EVO or from a file on your PC. Attention: only files saved with the XWEB-EVO can be loaded.

3.6.5.5 EXPORT PARAMETERS MAP

The parameter maps can be exported on CSV, PDF, XLS or WIZZMATE formats. Select "Export" and press "Execute". A window will appear from which to choose the format of the parameter map to be saved on your PC. Attention: the files will always be downloaded onto your PC in ZIP format.

The screenshot shows a file explorer window with the path 'Downloads > ParTab-03050013225751-RS1-002-New_XR570C.pdf.zip'. Below it, an Adobe Reader window is open, displaying the following content:


Device parameters

System name : Xweb EVO
 Device : RS1-002 New_XR570C
 Group : All
 Date : 03.05.2013 23:01
 Pages : 2

Index	Description	Label	value	Min	Max	Udm
1	Differential	Hy	4.0	0.1	25.5	°C
2	Minimum set-point	LS	-31.0	-50.0	0.0	°C
3	Maximum set point	US	20.0	0.0	150.0	°C
4	Output delay at power on	odS	0	0	255	min
5	Anti-short cycle delay	Ac	1	0	30	min
6	Fast freezing duration	cct	00:00			
7	Compressor ON with faulty probe	con	15	0	255	min
8	Compressor OFF with faulty probe	coF	30	0	255	min
9	Measuring unit	cF	°C			

3.6.6 DESKTOP SYSTEM LOGS

The "System Logs" desktop enables the user to visualise a list of events describing the most significant actions executed by the system and by the users accessing it.



On initial access, the system shows the list of all the events that have taken place in the last three days. The user can choose to apply different filters on the display.

- **Period:** setting the period to be considered and analysed
- **User:** to view the events of all users or of just one in particular
- **IP address:** to view the events whose source is a determined IP address. The address "127.0.0.1" corresponds to the address of an event generated by the same XWEBEVO system
- **Level:** to view the events of all levels or of just one in particular
- **Context:** to view the events of all contexts or of just one in particular

3.6.6.1 SYSTEM LOG EXPORT


The user accessing the page can export the table in an Excel file by clicking on "Export to File". The browser downloads an XLS file which, once opened, will appear as shown below:

systemLog-export-20130417150752-20130419150752.xls [Compatibility Mode] - Microsoft Excel						
Home Insert Page Layout Formulas Data Review View Developer						
A1						
A		B	C	D	E	F
1					System Name:	Xweb EVO
2					System Description:	XWEB EVO
3					Export Date/Time:	18/04/2013 23:16:55
4						
5	Date/Time	User	IP Address	Level	Context	Event
6	18/04/2013 18:04:57	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-002 New_XR570C (XR570C))
7	18/04/2013 18:05:36	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-002 New_XR570C (XR570C))
8	18/04/2013 18:09:31	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-002 New_XR570C (XR570C))
9	18/04/2013 18:18:28	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-002 New_XR570C (XR570C))
10	18/04/2013 19:40:11	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-003 New_XR70CX (XR70CX))
11	18/04/2013 20:10:30	Admin	10.100.80.167	info	Devices program	Read parameters (RS1-002 New_XR570C (XR570C))
12	18/04/2013 22:13:57	xwalm	127.0.0.1	info	alarm	Make email service
13	18/04/2013 22:14:09	xwalm	127.0.0.1	info	alarm	Make email service
14	18/04/2013 22:14:12	xwalm	127.0.0.1	info	alarm	Make email service
15	18/04/2013 22:17:33	xwalm	127.0.0.1	info	alarm	Make email service
16	18/04/2013 22:17:59	xwalm	127.0.0.1	info	alarm	Make email service
17	18/04/2013 22:20:37	xwalm	127.0.0.1	info	alarm	Make email service


3.7 SYSTEM ACCESS WITH PDA/SMARTPHONE

Open the browser of your PDA and enter the IP address of XWEB with the following syntax
http: // <IP> /xwebmobile/index.html


This will open the configuration page to sites with access PDA



Add your site (or sites) by pressing the (+) and please indicate name and IP address.




When you have completed the configuration of the sites, access them by clicking on the desired site.




Going to access the site, you will be presented with the login page. Enter Username / Password the user with whom you want access to EVO. If the machine has active alarms, it appears in the lower right icon red alarm signaling.




Upon entering, you are presented with the menu page navigation




1. Pressing on Devices, displays a list of the first device configured variables. If you wish to change their device, select it from the drop-down menu




2. Pressing on Alarms displays the page for displaying alarms



Pressing APPLY confirmed display filters and you will be presented the alarm list



Pressing on a specific alarm opens the detail page on the same alarm



For all pages presented above you you can navigate to the previous page by clicking the back arrow in the upper left (<).

4. TRADEMARKS

Consider It Solved and Intelligent Store are trademarks and Emerson Climate Technologies and the Emerson Climate Technologies logo are service marks and trademarks of Emerson Electric Co. Windows and Internet Explorer are registered trademarks of Microsoft Corporation in the United States and other countries.

Oracle and Java are registered trademarks of Oracle and/or its affiliates.

Firefox is a registered trademark of the Mozilla Foundation.

Yahoo! is a registered trademark of Yahoo! Inc.

Linux is a trademark registered to Linus Torvalds.

Other names may be trademarks of their respective owners.

5. ACCESSORIES

TYPE	DESCRIPTION	NAME	HOW TO ORDER	
MODEM	Serial analogue modem, compatible PDA, 56kbps.	XWEB MODEM	XWEBMODEM-200	24Vac
			XWEBMODEM-400	110Vac
			XWEBMODEM-500	230Vac
MODEM	Serial GSM modem, only to send SMS	TC35-KIT	TC35-KIT	
CABLE	Compatible network cable, 3m	###	CAB/WEB/NET	
CABLE	Compatible crossed network cable, 1m	###	CAB/WEB/PC	

6. FAQs

6.1 MAINTENANCE PROCEDURE FOR 300/500 MODELS

6.2 MAINTENANCE PROCEDURE FOR 3000/5000 MODELS

Should it be necessary to disconnect the XWEBEVO to move it or for cleaning purposes, remember that it should not be opened for any reason, or the warranty will be deemed invalid. Follow the procedure below, observing the rear panel figure as per the installation manual. The same is provided in paper form in the package and in electronic form on the Dixell website, under section "Manuals".

Press and quickly release the on/off power button (2);

Wait for all LEDs on the front to go off, including the PWR;

Disconnect external modem, if present (7);

Disconnect parallel printer or USB (6);

Disconnect monitor, keyboard and mouse (5);

Disconnect the telephone line and/or LAN network cable(4);

Disconnect RS485 terminals, relay and digital input (3)

Now disconnect the power supply cable (1) and move the XWEB;



Press and hold button (2) to force the instant switch-off of the system. When switch-off occurs in this way, the XWEB records the event, but cannot guarantee the correct data maintenance. The same applies for "forced" switch-offs which occur when the power supply cable is disconnected before the system is switched off.

6.3 I CANNOT ACCESS THE SYSTEM WITH MY PASSWORD

Check upper and lower case. The XWEB-EVO system is sensitive to the letter case.

6.4 MY BROWSER CANNOT REACH THE XWEB-EVO

Check the cables in use starting from that connected to your PC's network. Once the cables have been checked, check that the XWEB-EVO IP address can be reached: run the PING command from the command line to verify the correct routing of the packs on the network.

Example:




Figure 1

If no reply is received, your PC is unable to communicate with the XWEB-EVO. Check the cables once again or contact your network administrator. Attention, if a reply is received, it may not come from the XWEB-EVO: it may come from another device on the network. Also in this case, should you continue to have difficulties accessing via your browser, contact your network administrator for advice.

6.5 DISPLAYING OF INCOMPLETE OR INCORRECT PAGES FROM PC

The temporary browser or JAVA files, also known by the name cache-files, may sometimes prevent proper use of the XWEB-EVO. This happens when, for example, an XWEB-EVO is replaced and is accessed remotely using the same web address.

To solve this problem, delete these temporary files from your computer. Their deletion may vary depending on your operating system and its settings. Refer to your PC documentation and/or obtain the support of a computer expert or your network administrator.

- Below, the procedure for removing the cache from INTERNET EXPLORER 9:




Figure 2

- Below, the procedure for emptying the JAVA 1.6 cache:

click on Start button , click on Control Panel and then click on the JAVA icon. Click on “Settings” and “Delete Files...” (see figure below):




Figure 3

6.6 SOMEONE HAS RECEIVED A CONFLICTING MESSAGE ON THE IP ADDRESS

This may mean that the XWEB-EVO is using an IP address that is also being engaged by another network resource. We recommend changing the XWB-EVO IP with a new, free address. If in doubt on which address to use, contact your network administrator.

6.7 HOW MANY CONTROLLERS CAN THE XWEB-EVO MANAGE

The XWB3000/5000EVO can manage two separate RS485 serial lines simultaneously, for each of which it can address up to a maximum of 247 controllers. Therefore it can address up to 494 controllers on serial 485 in a Modbus-RTU network.

The XWEB300/500EVO can handle one serial line only. XWEB300EVO can manage maximum 18 controllers and XWEB500EVO can manage maximum 100 controllers.

6.8 HOW THE ALARMS ARE MANAGED

The XWEB-EVO monitors the alarm statuses and notifies any variations according to a configuration that must be set by the user. The person configuring the XWEB-EVO must perform the following steps in order to obtain a complete configuration:


3. System. The XWEB-EVO system anticipates that all notifications to an external media source (e.g. an email server) are configured in the system settings. See chapter 3.4.3 - SYSTEM CONFIGURATION in this manual.
4. Book. All recipients of the alarm notifications must be recorded in the system and must have their Email/fax contact details, or other, configured. See chapter 3.4.5 - USER/BOOK CONFIGURATION in this manual
5. Controllers It is necessary to define the controller network from which the XWEB-EVO will detect the alarm status of the same controllers. See chapter 3.4.4 - CONTROLLER CONFIGURATION in this manual
6. Alarms. It is necessary to define the rules according to which the detected alarms must be notified. See chapter 3.4.6 - ALARM CONFIGURATION in this manual. The alarms are grouped into alarm-categories that define how the alarm must be treated and to whom and how they must be notified. This information is defined on levels (aka. delivery settings).

6.9 HOW ARE THE ALARM EMAILS RE-SENT


The XWEB-EVO is often installed to notify alarms via email. The configuration of this media anticipates all steps described in point 6.8 - HOW THE ALARMS ARE MANAGED.

This service can be configured in various ways to re-send emails, should the alarm conditions persist over time:

1. The first type of re-send is carried out during the lifespan of the level, where the emails are always re-sent to the same recipients. The parameters affecting this type of re-send are "Resend Time" and "Resend life time", in the level settings.
2. the second type of re-send is carried out through means of an increasing notification level and the consequent notification being sent to a new group of recipients. The parameters affecting this type of re-send are the entry order in the levels in the category parameters (see image below) and the "Resend life time" in level settings.




3. the third type of re-send is carried out through means of an increasing notification interface and the consequent routing of email notifications on its media. This means that should the emails via the LAN interface fail to send, it is possible to manage their re-sending via a DIAL-UP (modem). The parameters affecting this type of notification are illustrated in the following image taken from the System configuration parameter email section.



6.10 TABLET COMPATIBILITY

The XWEB-EVO user interface is normally accessible via tablet web browsers; in particular, the pages in the DESKTOPS menu. The HTML pages are re-sized according to the size of the screen.



The machine configuration pages as well as some others are an exception and are not compatible:

- Menu→Tools→Compressor Rack Optimiser (for XWEB500/5000 models only)
- Menu→Tools→Performance Manager (for XWEB500D/500/5000 models only)

- Menu→Tools→Dew-Point Manager (for XWEB5000 models only)
- Menu→Tools→Supervisor System (for XWEB5000 models only)

A browser error may appear for the above pages


"Your browser understands the <APPLET> tag but is not running the applet for some reason." Your browser is completely ignoring the <APPLET> tag!

indicates that it is not possible for the tablet to open the page in question.

6.11 HOW TO MANAGE THE JAVA CERTIFICATES


The XWEB interface may require the use of a JAVA virtual machine installed on your computer. The JAVA6 and JAVA7 versions are those supported by the XWEB. This is necessary to run many applications present in the MENU→TOOLS such as Scheduler.

The first time a JAVA application is run, you will be requested to confirm the installation of the DIXELL certificates for the JAVA applications.



Click on the check box in order to accept and install the certificate. And then press "Run".

To check which certificates are installed on your PC, refer to the control panel (Windows) as in the image below.



6.12 HOW TO RUN XML READOUT

The XWEB-EVO returns, through means of a third party system, using an HTTP call via URL, the real time data of devices in a standard XML format.

Syntax:


http://<IP-ADDRESS>/cgi-bin/rt_format.cgi?DEVLST=<DEVICELIST>

where

- <IP-ADDRESS> corresponds to the IP address of the XWEB from where data is to be recovered.
- <DEVICELIST> corresponds to the list of device serial addresses. Should you wish to indicate multiple addresses, they must be separated by the character '|' (pipe). The indicated serial addresses are those configured on the tool and are relative to all configured tools-lines: the following example demonstrates how indicating address=2 returns two controllers (one for RS1 and one for RS2).

Example:

- http://10.100.81.208/cgi-bin/rt_format.cgi?DEVLST=2|3|247



<?xml version="1.0" encoding="UTF-8"?> = heading

<xwebEVO name="XWEB EVO SYSTEM NAME"> = basic branch in which it is indicated that the system is of type XWEB-EVO and its name

The basic branch reports the branches for each device indicated in the URL

The following attributes are returned for each device:

- name=device name
- adr=serial address of device
- uid=univocal address of device in configuration xweb. differentiates from adr for the ability to address the tools between the various serial lines
- lanid=serial line.

Example: <device name="New_XR570C" adr="2" uid="1" lanid="RS1">

Each variable in the device tree can be

- analogInput = analogue variable
- setPoint = set-point
- digitalInput = digital input
- deviceStatus = status of device
- outputStatus = status in output on device
- alarm = alarm

Each type specifies attributes:

Name = variable name. Example <name>"Low Value Pb1"</name>

Value = variable value, where present. For the analogue variables, the dot is used as a decimal separator; example: <value>6.2</value>. For the digital variables 0=not active 1=active 2=unknown; example: <value>1</value>. For the variables the value of which is not available: <value/>

[illegible]

Dixell S.r.l. - Z.I. Via dell'Industria, 27 - 32010 Pieve d'Alpago (BL) ITALY
Tel. +39.0437.9833 r.a. - Fax +39.0437.989313 - EmersonClimate.com/Dixell - dixell@emerson.com